



How-To-Use

SikaGrout® 212

Anchoring Grout

Materials:

- Safety glasses and gloves
- Bag of SikaGrout 212
- Sufficient water for desired mix
- Mixing container
- Mixing paddle
- Trowel or shovel (for smaller quantities)
- Drill and mortar paddle (for larger quantities)

Procedure

1. Remember to always wear waterproof gloves and safety goggles whenever mixing or using cement-based products.
2. Mix the grout with clean water in a separate mixing container for 3 minutes to obtain desired consistency. Add only enough water to achieve the flow required for the application. Less water for dry-pack consistency and more water for a fluid consistency. Maximum addition of water is 8.5 pints per 50 lb. bag.
3. Small quantities can be mixed with a trowel or shovel. For best results, larger quantities should be mixed with a slow speed drill and mortar paddle or a conventional mortar mixer.
4. Within 15 minutes of mixing, place the grout in the hole or void. Pour or ram grout as necessary, to fill the form area.



Guía de Uso

SikaGrout® 212

Anchoring Grout

Materials:

- Gafas de seguridad y guantes impermeables
- Bolsa de SikaGrout 212
- Suficiente agua para la mezcla deseada
- Recipiente de mezcla
- Llana o pala (para cantidades pequeñas)
- Taladro y paleta de mezcla or mezclador portátil para morteros (para cantidades grandes)

Procedure

1. Recuerde de siempre usar guantes impermeables y gafas de seguridad al mezclar y usar productos con base en cemento.
2. Mezcle el mortero con agua potable en un recipiente por 3 minutos hasta obtener la consistencia deseada. Añada únicamente el agua necesario para alcanzar la fluidez deseada para la aplicación (menos agua para una consistencia pastosa y más agua para una consistencia fluida). La máxima cantidad de agua es de 136 onzas fluidas por bolsa de 50 libras.
3. Cantidades pequeñas se pueden mezclar con llana o pala. Para mejores resultados, cantidades grandes se deben mezclar con taladro y paleta de mezcla o en un mezclador portátil para morteros.
4. El producto se debe colocar dentro de los 15 minutos después de mezclado. Según el caso, vierta or presione el producto dentro del espacio u hoyo para rellenar completamente el área preparada.