



HOW-TO GUIDE

SikaLatex[®] R

CONCRETE BONDING ADHESIVE AND ACRYLIC FORTIFIER

MATERIALS:

- Safety glasses and gloves
- 5 Gal. / 1 Gal. / 1 Qt. of SikaLatex[®] R
- Mixing container
- Wire brush

SITE PREP & PROCEDURE (As a Bonding Agent)

1. Remember to always wear waterproof gloves and safety goggles whenever mixing or using cement-based products.
2. Add 1 part cement, 2 parts sand, and a sufficient amount of SikaLatex[®] R to produce a creamy paint consistency.
3. Brush the mixture with a stiff bristle brush into the entire area to be resurfaced. Make sure the entire surface and all edges are covered.
4. Apply the repair mortar immediately, before the bonding agent dries.

SITE PREP & PROCEDURE (As an Admixture)

1. Add SikaLatex[®] R to repair mortar or concrete instead of water, and mix to a desired consistency. Follow the concrete or mortar instructions to correct proportions. Add more SikaLatex R as desired.