



## How-To-Use

# Sikagard<sup>®</sup> High Gloss Sealer

## Acrylic Concrete & Masonry Sealer

### Materials:

- Safety glasses and waterproof gloves
- Gallon of Sikagard High Gloss Sealer
- Desired application tool - sprayer, brush or roller

### Procedure

1. **Note:** A preliminary site test application is recommended (preferably on a small, prepped, inconspicuous surface) to determine satisfactory appearance and surface slip resistance.
2. Remember to always wear waterproof gloves and safety goggles. Insure that all surfaces are clean and sound. Remove all dust, dirt, loose concrete, grease, curing compounds, paint and other particles by mechanical means (i.e. pressure wash, blast clean, etc.).
3. Shake product thoroughly before applying.
4. Sikagard High Gloss Sealer can be applied by sprayer, brush or roller. Apply over the entire area moving in one direction. Additional coats can be applied for higher gloss.
5. Wait one day before exposing to foot/car traffic.

### Special Tips

- Substrate must be dry prior to application (minimum 48 hrs.)
- Protect from freezing
- Do not store in direct sunlight
- Do not apply if rain is in the forecast
- Concrete must be at least 14 days old
- Do not use over moving cracks
- Do not thin product



## Guía de Uso

# Sikagard® High Gloss Sealer

## Sellador acrílico de hormigón y mampostería

### Materiales:

- Gafas de seguridad y guantes impermeables
- El galón de Sikagard High Gloss Sealer
- Herramientas rodillo, aspersor o brocha

### Procedimiento

1. **Nota:** Se recomienda una aplicación preliminar de prueba en sitio (preferiblemente en una pequeña superficie preparada y poco visible) para determinar la apariencia satisfactoria y la resistencia al deslizamiento superficial.
2. Recuerde de siempre usar guantes impermeables y gafas de seguridad.
3. Agite el producto bien antes de aplicar.
4. El Sikagard High Gloss Sealer se puede aplicar con rodillo, brocha o aspersor. Aplique sobre toda el área moviéndose en una dirección. Se puede aplicar capas adicionales para un brillo mayor.
5. Espere un día antes de exponer al tráfico de peatonal y vehicular.

### Consejos

- El sustrato debe estar seco antes de la aplicación (mínimo 48 horas)
- Proteja de la congelación
- No almacene a la luz directa del sol
- No aplique si la lluvia está en el pronóstico
- El hormigón debe tener por lo menos 14 días de curado
- No use sobre grietas con movimiento
- No diluye el producto