

# DriftClip® DSLS Installation Instructions

## Vertical Deflection & Drift @ Bypass Structure

<p>Large Step Bushing (Engineered for PAF to structure)</p> <p>Standard Step Bushing (Engineered for #12 screw to stud)</p> <p><b>DriftClip® DSLS</b></p> <p>Step Bushings are pre-installed. Do not remove unless otherwise indicated.</p>	<p>Structural Member</p>	<p>Refer to Design Drawings for fastener type, size, and amount</p>
<p>Stud</p>	<p>Install screws using a screw gun that does not exceed 2,500 rpm.</p> <p>Screw gun must be equipped with torque limiting clutch to avoid fastener overdrive.</p> <p>#12 Screw</p>	<p>For Installation, Technical, or Submittal questions, contact TSN at (888) 474-4876.</p> <p>Email us at <a href="mailto:tsn@steelnetwork.com">tsn@steelnetwork.com</a>.</p> <p>Visit <a href="http://www.steelnetwork.com">www.steelnetwork.com</a> and discover the value of each TSN Solution.</p>