

VertiClip[®] SLB-HD Installation Instructions

Heavy Duty Vertical Deflection at Bypass Slab



VertiClip[®]
SLB-HD

Step Bushings are pre-installed. Do not remove unless otherwise indicated.

Structure

SLB-HD

Anchorage Option A:
(2) $\frac{1}{4}$ " Screws

Refer to Design Drawings for required fastener type.

Anchorage Option B:
(1) $\frac{1}{2}$ " Anchor

Refer to Design Drawings for required fastener type.

Install screws using a screw gun that does not exceed 2,500 rpm.

Stud

#12 Screws

Screw gun must be equipped with torque limiting clutch to avoid fastener overdrive.

For Installation, Technical, or Submittal questions, contact TSN at (888) 474-4876.

Email us at support@steelnetwork.com

Visit www.steelnetwork.com and discover the value of each TSN Solution.