



**NOTE:**  
 THIS DETAIL IS TO BE USED OVER WET-FILL  
 DECKS (VENTED) OR WHEN RE-ROOFING OVER  
 EXISTING MEMBRANE

CARE MUST BE TAKEN NOT TO SEAL THE TAMKO VAPOR-CHAN  
 TO THE PARAPET.

**BASE FLASHING FOR  
 VENTED BASE SHEET**

**AWP-3**

**TAMKO**  
 BUILDING PRODUCTS