


Fast Cap

For drywall pros searching for new ways to speed up their finishing jobs, we have the solution you're looking for: Fast Cap. Use this on doorways, wall ends, knee walls and closets to totally eliminate the need for finishing drywall faces and corner beads. 4 5/8" Fast Cap is designed for 2 x 4 wood studs only; the 4 7/8" Fast Cap can be used with wood studs or 3 5/8" metal studs. Fast Cap 3 1/2" and 3 3/4" are designed to be used with 2 1/2" metal studs.

Installation Guide

Technical Specs



Scan Below for
Installation Video



Step 1:



Step 2:



Before Installation:

Measure, cut and dry fit the bead.

Step 1:

If necessary, use a level to square into place.

Step 2:

Staple every 4"-6" using 1/2" staples.

Step 3:

Finish with drywall compound.

Step 3:

