

Contact: **1-800-872-5625**

Assembled Wind-Devil 2 Fasteners, Masonry Screws

Product #: MT-1

Assembled Wind-Devil 2 Fasteners with Self-Tapping Masonry Screws are ideal for securing EPS Foam Insulation to Masonry or Concrete. Easy to install. Use a hammer drill with a 5/32 bit to drill a clean pilot hole into the base material. Clear the hole of any excess debris, insert the screw and tighten. To prevent stripping of the base material be sure to tighten the screw slowly and avoid over torque. Available in a variety of sizes. Solid in box 1,000. Available in a variety of sizes. Solid in boxes 1,000. 5 bits include per 1,000 fasteners.

Package content

Product #:	Title	Variant	Quantity
RMWD-2PLATE			1
UM-1	UM-1 - 3/16in x 1-3/4in, Box of 1,000		1
M-MDB35	Relton Corp Carbide Drill Bit 5/32in X 3.5in		0.005
6198334			0.001
ASSEMBLY			1

People Also Purchased

Contact: **1-800-872-5625****DOW Standard Spray Foam
Applicator**

Product #: W-DEG13

\$31.45**Coleman Cable 500W S-
Handle Halogen Work Light**

Product #: W-DEL18

\$28.99**DeWALT VSR Drywall
Screwdriver 6.3amp 0-4000**

Product #: W-DW272

\$109.99**Hyde Tools Insulation Knife**

Product #: W-HY60118

\$44.17**More Info**

Part Code	Per Box	Insulation Thickness	Screw Size
MT-1	1000	1in only	3/16in x 1-3/4in
MT-2	1000	1-1/2in	3/16in x 2-1/4in
MT-3	1000	2in	3/16in x 2-3/4in
MT-4	1000	2-1/2in	3/16in x 3-1/4in
MT-5	1000	3in	3/16in x 4in

MT Series Masonry Pullouts

	1in	1-1/4in	1-1/2in	1-3/4in
Penetration				
Concrete Pullout Strength	380	580	830	1090
Hollow Block Pullout Strength	229	416*	452*	521*

**Denotes solid material*