

INSTALLATION OF  
STEALTH ACCESS PANELS  
BY WIND-LOCK®  
RETROFIT CONSTRUCTION



# BASIC INSTALLATION INSTRUCTIONS

- When installing a Standard Stealth Panel, make sure the frame and door remain together. If you need to separate the panel from the frame, be sure to mark it to match the frame it came with and store in a safe area.
- When installing a Round Stealth Panel, be sure the door is in the frame during installation or above the frame while installing. The door will not fit into the frame once the drywall is in place.
- When storing the panels, be sure they are all stored vertically in a safe, cool, dry place.



 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it. 



 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it. 





 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.













 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.





 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.







 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.





 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.











 **STEALTH**  
ACCESS PANELS BY WIND-LOCK

**Wind-lock**  
What you need. When you need it.





For more information  
Call 1 800-872-5625

or visit

[www.stealthpanels.com](http://www.stealthpanels.com)

