


Ecophon® Focus Ds Panel Accessibility


INSTALLATION MANUAL

Read the entire manual before installing.




To remove Certainteed Ceilings Ecophon Focus Ds panels, use clean white cotton gloves and follow the directions. Larger panels may require two people.

Installation for Ecophon® Focus™ Ds Panel Accessibility




Place your hand on the center of the panel and gently push up to disengage the panel.
Note: One edge will disengage higher than the other 3 sides.



While keeping upward pressure, gently slide the panel toward the edge that has disengaged.

Installation for Ecophon® Focus™ Ds Panel Accessibility



The panel will disengage as illustrated.