

Floor Cleaning Guidelines

Scan for cleaning videos, tips & more info!



DAILY CLEANING



1

Sweep and remove large debris and trash from the floor. Pay special attention to entrance doors and floor edges where dirt and dust are most likely to collect.



2

Spray the cleaning solution and scrub soiled and high traffic areas thoroughly. Pay special attention to entrances, furniture bases, and areas prone to spills and soil.



3

Fill the tank with fresh water and add CreteClean Plus. Do not add the cleaner before the water. This could result in unnecessary foaming.

Dilution Rate

CreteClean Plus 1 oz / gal (7.8 mL / 1L)
 CreteClean Plus 1.2 oz / 2-3 gal (35.49 mL / 7.5-11.3 L)
 Single Dose



4

Auto scrub the floor according to the equipment manufacturer's recommendations. As a general rule, an auto scrubber will clean approximately 500-1000 ft²/gal (12.3-24.5 m²/L) of cleaning solution.



5

Use a squeegee to pull any residual cleaning liquid away from the wall edges towards the center of the room.



6


When finished, pick up the remaining liquid with the auto scrubber.

SPILLS




1

Do not allow spills to dwell on the floor. Display "Wet Floor" sign and clean immediately with a damp mop.



2

Spray the affected area generously with CreteClean Plus cleaning solution to lift any remaining contaminants out of the concrete pores.



3

Mop the area a second time, ensuring that the cleaning solution and contaminants have been removed completely. Allow the floor to dry.



A Better Clean for Concrete Floors
www.cretecleanplus.com



cretecleantechnical@curecrete.com
 Technical Support



844.644.4304
 24 Hour Hotline

