


*Framing support columns
has never been easier!*

E-Z COLUMN Framing Collar

Quickly frame round support columns for finishing with drywall, paneling, etc.

E-Z Column Framing Collars are a hinged one piece construction for fast, easy framing around round columns. Collars fit both standard 3" and 3-1/2" steel columns. Use our blue collar for 4" supports.

E-Z as 1, 2, 3, 4



1

Determine column width

Measure your support column and determine if the column width is 3" or 3-1/2". Cut off and discard the center section (not spacer tabs). If column is 3" fold spacer tabs inward so that E-Z Column fits properly. If column is 3-1/2" remove and discard spacer tabs (see figure 1). Use the blue collars for 4" supports.

Screw

Spacer Tabs

Removable Center Section




Fig. 1



Fig. 2

2

Install E-Z Column

Spread E-Z Column open (see figure 2). Place around column starting with one at top and one at bottom. Add additional E-Z Columns as needed, spacing each 24" from the center of one E-Z Column to the center of the next E-Z Column (see figure 3). Five E-Z Columns are recommended for each 8' column.

3

Secure E-Z Column

Remove screw from the clip. Insert screw and slightly tighten. Make sure each E-Z Column is level and that the E-Z Column corners are squared and line up with each other (see figure 3).




Fig. 3



Fig. 4

4

Final adjustment

Tighten and adjust the screw on each E-Z Column (see figures 3 & 4) to ensure square corners. You are now ready to attach drywall, paneling, corner bead etc. E-Z Column will accept standard Grabber drywall screws as well as finishing nails.