

SuperDrive®

Automatic Screw Delivery System

0525XT

REPLACEMENT PARTS

- 1) Metal to Metal Nosepiece (CWFA01-03)
- 2) NosePiece Screw (CWFB13)
- 3) Indexing Module (CWFBC05)
- 4) Bit (CW153JBW or CW153)
- 5) Main Spring (CWS136-7)
- 6) Retaining Clip w/ Screw (CWFD08-1)
- 7) Indexing Body (CWDFD01-107)
- 8) Depth Control Bar (CWFD20-05)
- 9) Spring Washer for Depth Control (CWFD17)
- 10) Steel Locknut for Depth Control (CWFD19)
- 11) Depth Control Adjustment Ring (CWFD18)
- 12) Cap Screws x 2 (CWFD02-10)
- 13) Cap Screw x 1 (CWFD02-8)
- 14) Body Wing Screw (CWFD04)
- 15) End Plate (CWFD15)
- 16) Feed Track (F-TRACK)
- 17) Z-Clip Bar for F-Track (SBD)
- 18) F-Track Screws x 5 (CWF5)
- 19) Extension (SDEXT3)
- 20) Bit Extension (EXT520)
- 21) Handle Assembly (38227200)
- 22) MAKITA 6805BV, 2500 RPM
- 23) Deck / Drywall Nosepiece (CWFA01-01)
- 24) Makita Coupler (CPL6805BV)

