- Our Access Panels are designed to be maintenance free. However, it is recommended that the outer surface of the panel, and the hinge area, be kept clear from debris and dirt, to ensure correct operation of the hinged door.
- If latches, locks or hinges need to be lubricated, use a "3 in 1" type light oil, removing excess with a cloth.
- To clean painted surfaces, use a soft cloth and mild soap and water.
- To clean stainless steel, use a soft cloth and mild soap and water solution. After cleaning, thoroughly rinse with clear
 water to remove all traces of the solution and wipe dry to prevent water marks from forming. Stains which resist that
 treatment can usually be removed by polishing in the direction of the grain with a soft cloth and a non-abrasive
 stainless steel polish. Test in an unobtrusive location.





MAINTENANCE INSTRUCTIONS - ACCESS PANELS