
Pencil Rod Tightening Wrench

The AR Tightening Wrench is placed over a smooth or deformed rod behind a rod clamp and is used to draw the assembly tight, allowing the clamp to be properly tightened. The Tightening Wrench is available in ¼", 3/8" and ½" sizes.




To order, please specify the following information

EXAMPLE

APPROXIMATE SAFE WORKING LOADS 2:1 Safety Factor

| Diameter | | | |
|----------|--------|-------|-------------|
| mm | (in) | kN | (lbs) |
| 6 mm | (1/4") | 5 kN | (1,125 lbs) |
| 10 mm | (3/8") | 10 kN | (2,200 lbs) |
| 13 mm | (1/2") | 15 kN | (3,750 lbs) |



Caution: Do not use the Tightening Wrench for straightening forms or for pulling smooth rods from set concrete.