
## StiffWall®SW-S Light/Plus Boot Installation Instructions The Steel Network, Inc. (888) 474-4876





Products are designed and manufactured for the specific purposes shown, and should not be used in other applications unless approved by a qualified design professional. All modifications to products or changes in installation procedures should be made by a qualified design professional or installation contractor. The installation contractor is responsible for installation all products in accordance with relevant specifications and building codes.