

**T
69**

TECHNICAL BULLETIN

Tectum™ Composite - Placement of Attached Screws




Rev. April 2006

TECTUM Inc. • P.O. Box 3002 • Newark, OH 43058 • www.tectum.com • 1-888-977-9691

The location of attached screws for Tectum Roof Deck products is often varied. This drawing gives Tectum Inc. recommended locations. It should be noted that the screws are not placed at the edge of the panels but are spaced in from the edge depending on the width of the panels and the number of screws per joist. Special applications may require some modification of the spacing shown.

The location of attachment screws for Tectum roof deck products is often varied. This drawing gives Tectum Inc. recommended locations. It should be noted that the screws are not placed at the edge of the panels but are spaced in from the edge depending on the width of the panels and the number of screws per joist. Special applications may require some modification of the spacing shown.

Standard Screw Spacing for Tectum Plank Systems



For use with all Tectum screw and washer assemblies for Tectum I, III, E, and NS plank and waterhead screws for Tectum III, E, and NS plank.

REVISIONS				DATE	SCALE	DRAWING NUMBER
NO.	DATE	BY	REMARKS			
				2/22/95	none	RP10

Tectum
Roof Plank Screw Spacing

DATE: 2/22/95
SCALE: none
DRAWN: idb
CHECKED:
APPROVED:
DRAWING NUMBER: RP10
CAD FILE: RP10