

Simple-Fix EZ

ENGINEERED WOOD FLOORING REPAIR KIT

TECHNICAL DATA SHEET 05/08/2025

SMART ADVANTAGES

- Fills hollow spots
- Flows easily
- Replaces 2-part epoxy

DESCRIPTION

Simple-Fix EZ is solvent-free adhesive used to repair common installation issues associated with engineered flooring. This easy-to-use system can correct installation issues such as hollow spots caused by incomplete contact of the original adhesive and irregular substrates. Simple-Fix EZ can also correct issues in problem areas from improper application of the original adhesive, which resulted in a poor bond. The Simple-Fix EZ system is ready to use and replaces costly and sometimes messy two-part epoxy systems.

Each kit comes complete with all the accessories needed to repair the engineered wood floor installation.

DIRECTIONS FOR USE

Important: Read instructions completely. If you have questions, contact Bostik Technical Department at 706-508-5907, Mon-Fri, 8:00 am - 5:00 pm EST before you begin.

SUBSTRATES AND FLOORING TYPES:

Use on all substrates for the repair of engineered wood flooring only.

Identify all of the areas that require repair and prepare them at the same time. Doing all repairs at the same time will reduce the chance of the Simple-Fix EZ drying in the syringe.

- Drill hole(s) with the 3/32" drill bit provided. Masking off the area with tape will protect the surrounding floor. More than one hole may be required depending upon size of the hollow spot. For larger areas, at least two holes are recommended. Drill a hole at each side of the area to be repaired.
- 2. Fill the syringe with Simple-Fix EZ by drawing up adhesive directly from the bottle into the syringe.

NOTE: Adhesive is thin – It may drip without pressure being applied to the syringe.

Place the applicator tip into the hole and inject adhesive until you feel back pressure. If two holes were drilled, inject adhesive until it comes out of the other hole. Inject adhesive into the second hole to be sure the entire area has been filled.



- 4. Do not weigh down the repaired area; this allows the adhesive to seek its own level.
- 5. Use the dowels provided in the kit as a plug for the hole(s) drilled. This will keep the adhesive trapped beneath the floor. The dowels will fit tightly in the hole. Tap the dowel into the hole and cut it off even with the floor. Use a punch to drive the dowel below the surface of the flooring.
- 6. Putty the hole with wood filler.
- Clean up any adhesive residue with a damp cloth. Dried adhesive may be removed with an appropriate solvent cleaner. Wash out syringe and applicator tip with warm water while still wet so that it can be reused.

This repair system can be used with most glue-down engineered wood floors, provided the original adhesive has completely cured. It is up to the installer to check installation for compatibility if the original adhesive was not manufactured by Bostik.

NOTE: If the repair area was large, some cupping of the flooring may occur. Cupping is a natural occurrence that sometimes happens when moisture at the bottom of the board exceeds the moisture at the top of the board — cupping should not be considered an adhesive or labor defect. This is usually a temporary occurrence that will disappear when the board moisture returns to equilibrium.

This supersedes and replaces in its entirety all previously published versions of this document. B179122

TRAFFIC

Follow the flooring manufacturer's installation guidelines; otherwise restrict foot traffic for 24 hours after repair. No heavy traffic, rolling loads, or furniture placement for 72 hours after repair. Additional time may be necessary if the repair is over a non-porous substrate.

CLEANUP

To clean up while wet, use soapy water. Dry residues may require the use of a denatured alcohol.

STORAGE/SHELF LIFE

The product should be stored in the original container in a cool, dry place and out of direct sunlight. Do not allow product to freeze. If the product should freeze, store at 75°F (24°C) until completely thawed, then thoroughly mix contents. Test carefully to ensure the product performance has not been compromised. Shelf life is one year from date of manufacturing in unopened, original packaging when stored at temperatures between 65°F (18°C) and 95°F (35°C).

LIMITATIONS

- · Protect from freezing
- Use on all substrates for the repair of engineered wood flooring only.
- · Do not use to repair solid wood or bamboo

PACKAGING

One Quart refill bottle

Repair Kit

ACCESSORIES INCLUDED IN KIT

- Simple-Fix EZ repair adhesive quart (1)
- Application syringe (1)
- 3/32" drill bits (2)
- Wood dowels (8)
- Luer Lock blunt tips (2)
- Punch (1)

PRODUCT DISCLAIMER

All information contained herein is believed to be accurate as of the date of publication, is provided "as-is" and is subject to change without notice. This is not a warranty, an agreement, or substitute for expert or professional advice. Bostik, Inc. ("Company") expressly disclaims and assumes no liability for the use of the products or reliance on this information. It is the sole responsibility of the user to determine the suitability of any products for user's application(s). NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE PRODUCTS OR THE INFORMATION PROVIDED HEREIN. The information provided relates only to the specific products designated herein and may not be valid where such products are used in combination with other materials or in any process. The performance of the product, its shelf life, and application characteristic depends on many variables, and changes in these variables can impact product performance. You are responsible to test the suitability of any product in advance for any intended use or application and before commercialization. Nothing herein shall be construed as a license for the use of any product in a manner that might infringe any patent and it should not be construed as an inducement to infringe any patent. Please carefully review the Safety Data Sheet for the product.

LIMITED WARRANTY found at www.bostik.com/us. TO THE MAXIMUM EXTENT ALLOWED BY LAW, BOSTIK DISCLAIMS ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. UNLESS OTHERWISE STATED IN THE LIMITED WARRANTY, THE SOLE REMEDY FOR BREACH OF WARRANTY IS REPLACEMENT OF THE PRODUCT OR REFUND OF THE BUYER'S PURCHASE PRICE. BOSTIK DISCLAIMS ANY LIABILITY FOR DIRECT, INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES TO THE MAXIMUM EXTENT ALLOWED BY LAW. DISCLAIMERS OF IMPLIED WARRANTIES MAY NOT BE APPLICABLE TO CERTAIN CLASSES OF BUYERS AND SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. It is the buyer's obligation to test the suitability of the product for an intended use prior to using it. The Limited Warranty extends only to the original purchaser and is not transferable or assignable. Any claim for a defective product must be filed within 30 days of discovery of a problem, and must be submitted with written proof of purchase.

Bostik, Inc. 11320 W. Watertown Plank Road Wauwatosa, WI 53226 www.bostik.com/us

BOSTIK HOTLINE

Smart help 1-800-726-7845

Legal Disclaimer: All information contained herein is believed to be accurate as of the date of publication, is provided "as-is" and is subject to change without notice. This is not a warranty, an agreement, or substitute for expert or professional advice. Bostik Inc. expressly disclaims and assumes no liability for the use of the products or reliance on this information. It is the sole responsibility of the user to determine the suitability of any products for user's application(s). NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED (INCLUDING SUITABILITY FOR USE IN ANY MEDICAL DEVICE OR MEDICAL APPLICATION), IS MADE CONCERNING THE PRODUCTS OR THE INFORMATION PROVIDED HERRIN. The information provided relates only to the specific products designated herein and may not be valid where such products are used in combination with other materials or in any process. The performance of the product, its shelf life, and application characteristics depends on many variables, and changes in these variables can impact product performance. You are responsible to test the suitability of any product in advance for any intended use or application and before commercialization. Nothing herein shall be construed as a license for the use of any product in a manner that might infringe any patent and it should not be construed as an inducement to infringe any patent. Please carefully review the Safety Data Sheet for the product.