



CertainTeed Technical Services Memo

Subject:	Maintenance Instructions for CertainTeed VinylShield A + C acoustic ceiling panels		
Date:	January 18, 2024	Tel:	800-233-8990

Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed they should be taken completely out of the grid and stored on a flat surface. Panels should be laid face to face in order to prevent unnecessary soiling and damage during their temporary displacement.

Cleaning

Wipe surface of the panel using a clean, white cloth dampened with a water and mild liquid detergent solution (such as Dawn Ultra® dish soap). Do not moisten panel excessively. Never soak panels with water.

Disinfecting

Panel disinfecting may be accomplished by the use of a colorless disinfectant solution in the manufacturer's recommended dilution. Spray the selected disinfectant lightly on the panel surface and wipe with a clean, white cloth. Examples of acceptable colorless disinfectants are: hydrogen peroxide, isopropyl alcohol, quaternary ammonium and sodium hypochlorite.

**If any portion of this information provokes a question, please contact
CertainTeed Technical Services.**