## Flowfresh® MF

Heavy Duty Cementitious Urethane Self-Leveling Industrial Floor System

#### **Technical Data Sheet**



#### **DESCRIPTION:**

Flowfresh® MF is a three-component antimicrobial cementitious urethane floor resurfacer. This heavyduty, self-leveling floor topping incorporates specially graded aggregate to produce a highly durable, smooth textured floor finish that provides positive slip resistance. Flowfresh® MF offers exceptional chemical, abrasion impact and thermal shock resistance for interior and exterior application.

To protect the floor, all Flowfresh® products include Polygiene®, a built in, highperformance antimicrobial additive that inhibits growth of bacterial odors and degradation from guards against microorganisms.



#### **TYPICAL USES:**

- **Bakeries**
- Clean rooms
- Laboratories
- Manufacturing, medium duty
- Powder production rooms
- Printing (inks/dyes)
- Pulp and paper processing
- Warehouses

#### ADVANTAGES:

- Withstands thermal shock & thermal cycling
- Superior chemical, impact, abrasion resistance
- Positive slip resistance
- Low odor, zero VOC formulation
- Can be applied to green concrete; withstands higher levels of moisture vapor transmission \*\*
- Built in Polygiene® performance antimicrobial
- Integral cove base/curb (Flowfresh® CM)

#### **GENERAL PRODUCT INFO:**

Standard Colors: Red and Gray Coverage: See "coverage" section Pot Life: 10 minutes @ 68F Application Method: Gauge Rake, Trowel Cure Rate: 6-24 hours Shelf Life: 6 months unopened

TYPICAL PHYSICAL PROPERTIES:		
TEST TYPE	<b>TEST METHOD</b>	<b>TYPICALVALUE</b>
Compression	ASTM C-579	8,000 psi
Strength:		
Tensile Strength:	ASTM C-307	870 psi
Flexural Strength:	ASTM C-580	2,900 psi
Impact Strength:	ASTM D-4226	>160 in/lbs.
Abrasion	ASTM D-4060	120 mg loss
Resistance:		
Bond Strength:	ASTM D-4541	>300psi
Heat Resistance:	Maximum	210°F
Microbial / Fungal	A.A.T.C.C. Test	100% Contact
Control*:	Method 147-1993	Inhibition

<sup>\*</sup>The inclusion of Polygiene® within the screed matrix of the industrial floor system ensures the permanency of this biocidal additive even in the event of excessive surface wear. Polygiene employs ionic silver, a natural antimicrobial agent with well-known efficacy. Silver ions continuously migrate to the contact surface where, through multiple mechanisms of action, they inhibit growth of microorganisms. This antimicrobial process remains active 24 hours a day, 7 days a week.

#### **PACKAGING:**

Kits are packaged in pre-proportioned containers as follows:

> 1 container of Part A 1 container of Part B 1 bag of aggregate Part C

#### FLOWFRESH® BODY COAT COVERAGE:

18 ft.<sup>2</sup> per kit @ 1/4" 36 ft.2 per kit @ 1/8"

<sup>\*\*</sup> Consult Technical Service for limitations

#### LIMITATIONS:

- Please consult Technical Service for application over new concrete less than 28-day cure. Do not apply to previously treated concrete with curing and parting compounds or other epoxy/urethane coatings, unless they have been completely removed by chemical or mechanical means.
- · Protect from freezing.
- Can be used on quarry tile, dairy tile, and acid brick if the supporting substrate is sound. Contact your local Valspar flooring representative for additional information.
- Do not apply if air temperature is within 5F of dew point.
- Do not apply if the floor or air temperature is below 40°F or over 85°F or if the relative humidity is above 85%.
- Do not apply over honeycombed or structurally unsound surfaces.
- Do not thin this product.
- Before applying for protection against specific chemical environments, consult Chemical Resistance Guide or Technical Service.
- If the product is to be applied in or near areas containing food products, they should be removed before the application and until the coating has fully cured and all vapors have dissipated.
- Technical Data Sheets are updated periodically. To ensure the current version is being used, please visit the Technical Resources portion of Valspar Flooring's website at www.valsparflooring.com.
- Proper material application is the responsibility of the user. Site visits by Valspar personnel are for making technical recommendations only and not for supervising or providing quality control.

#### PRELIMINARY FLOOR INSPECTIONS:

In general, the area to be surfaced must be clean, sound, dry and above 45% to assure a successful installation. Concrete must be at least 28 days old. Consult Technical Service for application over concrete less than 28-day cure.

Always be alert to any possible airborne or surface contaminants, which may contribute to problems such as fisheyes, crawling, cratering, etc.

The concrete floor should be examined for the presence of moisture. This can be accomplished by the following means:

Calcium Chloride Test: This test method works by a change in weight of moisture absorbing anhydrous calcium chloride and indicates the amount of moisture transmitting out of a large concrete surface area. Pounds is the equivalent weight of the water that is emitted from a 1,000 square foot concrete slab surface area in a 24-hour period of time (standard test duration is 60 hours). Concrete must not show moisture content greater than three pounds per 1,000 square feet in 24 hour time frame. Follow instructions as outlined by the supplier of the test kits. Make sure the concrete surface to be tested is completely clean of any residue and any debris. All seals. including curing compounds must be removed prior to performing tests. Sources: Roofing Equipment Inc., Denver, CO 303-371-7667; Sealflex Industries Inc., Costa Mesa, CA 714-708-0850; Vinyl Plastics Inc., Sheboygan, WI 920-458-4664; and Floor Seal Technology, San Jose, CA 408-436-8181

#### **SURFACE PREPARATION:**

All oil, grease, wax, laitance, curing compounds, watersoluble concrete hardeners and other surface contaminants must first be removed. Inspect the concrete and remove loose or soft concrete by shot blasting or scarifying.

#### **STANDARD TESTS:**

Refer to the standard test methods below for further information.

ASTM D 4258-83 Standard practice for surface

cleaning concrete for coating

ASTM D 4259-83 Standard practice for abrading

concrete

#### **MECHANICAL PREPARATION:**

Mechanically abrade or "shot-blast" the surface to the texture of medium/heavy grade sandpaper. Alternate methods may include scarifying. All terminations and transitions should have a saw cut and be chased approximately 3/8" deep. Saw cuts should be installed around the perimeter of the area, approximately 6"-12" from the wall. They should also be installed around drains, equipment and pads, as well as every 8'-12' over the concrete substrate. Sweep and vacuum remaining dust.

Whenever "shot-blasting" is utilized, be careful to leave concrete with a uniform texture. Over "blasting" will result in reduced coverage rates.

#### PREPARATION:

Before proceeding with the mixing and application of Flowfresh® MF, the surface should be checked to make sure it is properly prepared and the temperature of the area and floor is above 40°F. In addition, a mixing area should be set up nearby with the necessary equipment and materials are in order. Material should be stored in a dry area at 50-65°F. Cold material will significantly reduce application properties.

#### Patching:

If patching is required, Flowfresh  $^{\otimes}$  HF or RT can be used to depths of  $\frac{1}{2}$ ".

#### Expansion Joints:

Cut control joints in flooring with concrete saw. Clean with wire brush and blow or vacuum clean. Joints should be clean, dry and free of any dirt, laitance or any other surface contaminants.

#### Edge Terminations:

Chasing floor edges is recommended to distribute thermal and mechanical stresses. "Key" all points of termination.

#### MIXING AND APPLICATION:

#### PRIMING:

- Priming is required when applying the MF system.
  Utilize the FC Coating material as the primer coat.
- Use a drill and jiffy to pre-mix the part A resin for 1-2 minutes.
- Pour together the part A and B and mix for approximately 1 minute. Add the part C aggregate slowly at a rate of 30 seconds per bag.
- Pour the mixed material in a ribbon about 8"-12" wide and using a flat squeegee pull the material across the floor and then back roll using a 3/8" nap roller.
- Roll to evenly apply the material at about 160-185 sq.ft./gallon.
- After cure about 6-8 hours the MF system can be installed.
- The recoat window of the primer is 6-24 hours depending on temperature and humidity, screening will be required if the recoat time has passed.

#### MF APPLICATION:

- Use a drill and jiffy to pre-mix the part A resin for 1-2 minutes. Pour part A resin into mixing vessel. (Bucket or mortar mixer is recommended.)
- Pour in part B hardener and mix for 30 seconds minimum.
- Add part C aggregate slowly at a rate of 30 seconds per bag. Continue mixing until all the aggregate is blended and the color is consistent.
- Quickly transport mixed material to the area to be overlaid; pour mixed material onto the floor in a ribbon pattern. Using a screed rake, gauge rake or notched trowel, place the material at desired thickness. Moving quickly continue to place mixed material, blending it into the previous path, within 10 minutes.
- After the material is at the desired thickness, immediately roll with a porcupine roller up and back through the material.

#### TOPCOAT FOR FLOWFRESH® MF:

It is not required to topcoat the MF, but the recommended topcoat is Flowfresh® FC Coating or utilizing one of the epoxies or urethanes from the Valspar line.

**NOTE:** If one of Valspar's epoxies or urethanes is being used as the topcoat, the MF system must be screened and cleaned with IPA, prior to the application of the topcoat. Please refer to the data sheet for application instructions.

**NOTE:** If a topcoat other than the Flowfresh<sup>®</sup> FC is used, the performance properties of the antimicrobial agent Polygiene<sup>®</sup> will be sacrificed.

### **POT LIFE:**

Approximately 10 minutes at 68°F.

#### **CURE TIME:**

At a cure temperature of 70°F, allow 12 hours for foot traffic, 24 hours for light to medium loads and allow 48 hours for heavy fork lift traffic and chemical spillages. Fully cured after 7 days.

Flowfresh® MF Page 4 of 4

#### **MAINTENANCE:**

Please consult the manufacturer regarding maintenance information.

#### **SAFETY:**

For detailed safety guidelines, please refer to the product Material Safety Data Sheet (MSDS). For additional information, contact your local representative.

#### **CLEAN UP:**

Solvents such as Xylene can be used.

# REFER TO MATERIAL SAFETY DATA SHEET FOR FURTHER SAFETY AND HANDLING INFORMATION.

See individual labels for more caution statements.

#### KEEP OUT OF THE REACH OF CHILDREN.

#### **DISPOSAL:**

Dispose in accordance with federal, state, and local regulations. Use licensed hazardous waste company.

Empty containers may contain product residue, including flammable or explosive vapors. Do not cut, puncture or weld on or near container. All label warnings must be observed until the container has been commercially cleaned or reconditioned.

© Copyright 2006 Valspar Corporation. All rights reserved. Flowfresh<sup>®</sup> is a registered trademark of Flowcrete PLC. Polygiene<sup>®</sup> is a registered trademark of Polygiene AB. TDS-FlowfreshMF | Rev 02/26/07 ly