## **WP-4** FAST DRY 550 POLY SEALER

## **Technical Data Sheet**

## **DESCRIPTION:**

Oil modified sanding sealer. A clear coating formulated and recommended for application to bare wood to seal it and provide a surface for the finish coats.

## ADVANTAGES:

- Superior fast drying polyurethane
- Superior film hardness
- Deep penetration into wood
- Lightness in color
- MFMA approved product

## PACKAGING:

Product is available in 1 and 5-gallon containers.

## COVERAGE:

Bare wood seal300-400 sq. ft/ gal.Recoat window 1 - 10 hrs.Build coats400-500 sq. ft/ gal.Recoat window 2 - 10 hrs.

## **ASSOCIATED PRODUCTS:**

- WP-15 Waterless cleaner
- VALSPAR Paints/ Stains

## **RELATED EQUIPMENT:**

- Single disc floor machine, low speed (150 200 rpm).
  17 20-inch diameter #100 and #120 grit Abrasive disc screens.
- 24 inch push broom for sweeping and tacking
- Terry cloth towels for use as tack rags
- Putty knife or scraper
- K-200 E-Z way applicator and KV-4400 replacement pads.

## SURFACE PREPARATION:

Note: Follow MFMA and NOFMA guide lines for acclimation time of wood prior to installation, sanding, and finishing.

Floor must be free of contamination like oils, silicones, waxes, fillers, and stains that contain stearates. These can cause adhesion problems.

GENERAL PROPERTIES:		ASTM
Color	4 - 6	D1544
Viscosity	A3 – A2	D1545
Weight/Gallon	7.1 - 7.3 Lbs.	D1475
Solids	36+/- 1%	D1644
Flash Point	105°F	D56
VOC	<550 g/L	
MFMA TESTS:	-	
Sanding	Pass	
Hardness	Pass	
Abrasion resistance	Pass	
Flexibility	Pass	
Coefficient of friction	Pass	
Maintenance	Pass	
CHEMICAL RESISTANCE:		
Stain resistance	Pass	
Alcohol resistance	Pass	
Naphtha resistance	Pass	
Cola resistance	Pass	
Beer resistance	Pass	
Perspiration resistance	Pass	

## **DIRECTIONS:**

NOTICE: THIS PRODUCT IS DESIGNED TO BE USED AS IS THEREFORE THINNING OR REDUCING WITH SOLVENTS IS NOT RECOMMENDED.

#### Newly installed floors or sanded to bare wood

- 1) Screen the floor using #100 grit screens (250 sq. ft per side).
- 2) Vacuum, then tack rag the floor with **WP-15 waterless** cleaner.
- 3) Allow the floor to dry to a dull, glossless surface.

## WOOD STAINING:

#### **Recommended Stains:**

#### VALSPAR Interior wood stains

- 1) Compatibility of the stain with the top coat should be tested for adhesion.
- 2) Apply the stain following the label instructions.
- Wipe off any excess material with the grain, and allow it to dry thoroughly. Lightly sand before seal coat application.

#### Seal coat application

- With an EZ-way applicator, lambs wool applicator, or a foam pad seal the bare wood with WP-4 Fast Dry Sealer.
- 2) Allow 2-4 hours dry with good ventilation for each coat.
- 3) Minimum of two coats of **WP-4 Fast Dry Sealer** is recommended.
- 4) Remove raised grain with a #120 grit screen, then tack rag with **WP-15 waterless cleaner**.
- 5) Line marking paint can then be applied.

## VALSPAR FLOORING

## LINE MARKING:

#### Recommended paints VALSPAR Anti-Rust enamel paints

- Before using paint every color should be tested for compatibility, not just brands.
- Apply line markings between the second and third coats. Follow the directions on the paint label for application.
- 2) Lay out the court with masking tape as required and apply the paint.
- 3) To ensure crisp lines allow paint to dry 1-2 hours before pulling up the tape.
- 4) Allow the lines to dry for a minimum of 24 hours.
- 5) Abrade the lines lightly with #120 grit screens.

## FINISH COATS:

Finish with two additional coats of sanding sealer like: **WP-4 gloss.** 

Finish with two coats of varnish like:

WP-1, WP-2, or WP-8.

Finish with three coats of water based finish like: **WP-10, AQUA GUARD I, or AQUA GUARD II.** 

Adequate ventilation is imperative during the curing process. Dry times will vary based upon the drying conditions. Do not apply when temperature is above 95 F or below 65 F, or when humidity is above 80%. Clean up with mineral spirits.

## **TROUBLE SHOOTING:**

Slow dry:	Low curing temperatures, High humidity, Lack of ventilation, and air movement after application.
Streaks:	Product applied too thin.
Fisheyes:	A foreign material on the surface, like oil, grease, or silicone.
Wrinkling:	Recoating too soon, Too heavy an application, puddling the finish.
Bubbling:	Overworking the product with applicator, shaking the finish before applying, High temperatures during application.
Peeling:	Improper floor preparation.
Dirt particles:	Applicator Not "De-Fuzzed" loose fibers in the film, Room vents not sealed during the application.
Screen marks:	Using a too aggressive screen between coats.

## **CAUTION:**

- 1) Keep away from heat and flames.
- 2) Avoid prolonged breathing of vapors or mist.
- Open doors and windows to ensure fresh air entry during application and drying. If necessary wear respiratory equipment (NIOSH/ MSHA TC-23C or equivalent).
- 4) Avoid skin contact, eye contact, or clothes contamination.

## FIRST AID:

- 1) Skin contact wash with soap and water.
- 2) Eye contact flush with water for 15 minutes and get medical attention.
- 3) If swallowed do not induce vomiting, get medical attention immediately.
- If experience watering eyes, headaches, dizziness, nose or throat irritation, increase the flow of fresh air, or leave the area.

## NOTICE:

- SPONTANEOUS COMBUSTION: Dust created from screening oil based finishes and rags soaked with oil and dust can auto-ignite causing a fire. DO NOT store or throw away the dust and oil soaked rags into a closed vacuum or trash can. Immerse the dust in water and open the rags to air dry before discarding the waste. High temperatures, high humidity and freshly applied seal increase the potential for a fire.
- Long term overexposure to solvents have been associated with permanent brain and nervous system damage. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful or fatal.
- 3. In case of a spill absorb with inerts like sawdust or "oil dry" and wipe clean with **WP-15 waterless cleaner.** Dispose in accordance with local regulations.
- 4. Empty containers may contain product residue, including flammable or explosive vapors. Do not cut, puncture, or weld on or near container.

## **DISPOSAL:**

All label warnings must be observed until the container has been commercially cleaned, reconditioned, or disposed of in accordance with local government regulations.

**Refer to Material Safety Data Sheet** for further safety and handling information.

# For Emergency Medical Information call 1-888-345-5732

## KEEP OUT OF REACH OF CHILDREN

© Copyright 2007 Valspar Corporation. All rights reserved.

TDS-WP4 | Rev 12/18/07 ly

WARRANTY STATEMENT | IMPORTANT: The data on this sheet represent typical values obtained by the methods indicated. Since application variables are a major factor in product performance, this information should serve only as a general guide. Valspar assumes no obligation or liability for use of this information. Unless Valspar agrees otherwise in writing, VALSPAR MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND DISCLAIMS ALL IMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR FREEDOM FROM PATENT INFRIGNEMENT. VALSPAR WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. Unless Valspar agrees otherwise in writing, Valspar's only obligation for any defect in this product under any warranty that Valspar provides or under any other legal theory will be to replace the defective product, or to refund its purchase price, at Valspar's option. Revision E: 12 FEB 2002