






WATERPROOFING OF CONSTRUCTION JOINTS, EXPANSION JOINTS & CRACKS AQUAFIN-2K/M & JOINT SEALING TAPE

Schematic sketches



A-1 & A-2. Sealing of construction joints and cracks:

- ① Apply 1st coat of AQUAFIN-2K/M, extending min. 3/4" (20 mm) beyond either side of tape.
- ② Embed JOINT SEALING TAPE-2000 uniformly into 1st coat of AQUAFIN-2K/M, leaving no wrinkles.
- ③ Cover JOINT SEALING TAPE-2000 with 2nd coat of AQUAFIN-2K/M (same or next day) and smooth the surface with a damp brush.
Note: Use JOINT SEALING TAPE-2000-S for areas subject to larger movement.



B-1. & B-2. Sealing of expansion joints, using 1 tape:

- ① Apply 1st coat of AQUAFIN-2K/M, extending min. 3/4" (20 mm) beyond either side of tape.
- ② Embed JOINT SEALING TAPE-2000-S uniformly into 1st coat of AQUAFIN-2K/M, leaving no wrinkles. Allow sufficient slack to accommodate joint movement.
- ③ Cover JOINT SEALING TAPE-2000-S with 2nd coat of AQUAFIN-2K/M (same or next day), stopping at joint edge, and smooth the surface with a damp brush.
- ④ For version B-2, fill void with caulk.

C. Sealing of expansion joints using 2 tapes:

- Follow steps 1 - 2 as in item B-1.
- ③ Insert backer rod.
- ④ Cover 1st tape with a coat of AQUAFIN-2K/M, stopping at joint edge, and while still fresh embed 2nd tape.
- ⑤ Cover 2nd tape with a coat of AQUAFIN-2K/M, stopping at joint edge. Smooth surface with a damp brush.

Refer to standard specifications and product data sheets for further information.