

# **ARDEX SD-T**

### Self-Drying, Self-Leveling Concrete Topping

Smooth new or existing concrete and certain non-porous surfaces Install from 1/4" up to 2" neat, and up to 5" with aggregate Walk on and seal in as little as 2 hours For commercial, light industrial and residential applications Especially suited for ARDEX DESIGNER FLOORS Available in white and gray

> ARDEX Americas 400 Ardex Park Drive Aliquippa, PA 15001 USA 888-512-7339 www.ardexamericas.com

## ARDEX SD-T

### Self-Drying, Self-Leveling Concrete Topping

### **Suitable Substrates**

- Concrete (structurally sound)
- Absorbent terrazzo on concrete† (Contact ARDEX Technical Service for instructions)
- Properly installed ARDEX moisture control systems on concrete
- Other approved, non-porous materials on concrete (Contact ARDEX Technical Service for instructions):†
  - Ceramic, quarry or porcelain tiles
  - Non-porous (non-absorbent) cementitious terrazzo

†Must be sound, solid and well-bonded to underlying, structurally sound substrates. It is the responsibility of the installation contractor to ensure the substrate is rigid, well supported, properly anchored and free of undue flex and vibration.

### **Suitable Applications**

- All grade levels
- Dry areas only
- Interior applications only
- Areas to receive foot and/or moderate, rubber-wheeled forklift traffic and similar\*
- Not for heavy-duty manufacturing, industrial floors or chemical environments requiring customized industrial toppings

\*Excessive service conditions such as and similar to the following will cause gouging and indentations:

- Steel- or hard plastic-wheeled traffic
- Dragging heavy metal equipment, loaded pallets with protruding nails, heavy furniture and/or fixtures over the floor

### **Job Conditions**

During installation and cure, substrate and ambient temperatures must be a minimum of 50° F / 10° C.

### Step 1: Moisture Evaluation and Testing

This product is intended for interior, dry spaces. Hydrostatic pressure, plumbing leaks, flood factors and other sources of water infiltration must be identified and corrected prior to installation. This product is not a vapor barrier and will allow free passage of moisture vapor. Test concrete in accordance with ASTM F2170. Moisture control is required if the RH exceeds the limitations imposed by the sealer or coating manufacturer.

Priming course if moisture control is required: ARDEX MC RAPID. If moisture control is not required, See section entitled "Priming Method Selection" below.

### Priming Method Selection (If moisture control is not required)

- ARDEX P 51<sup>™</sup> Primer
- ARDEX EP 2000;
- ARDEX MC RAPID (primer application)

Substrate (Dry areas only Interior applications only; All grade levels)	Priming Course
Extremely absorbent concrete	ARDEX P 51 Double prime
Non-porous (non-absorbent) cementitious terrazzo	ARDEX EP 2000
Standard absorbent (porous)	ARDEX EP 2000;
Concrete; Aesthetically critical	ARDEX MC RAPID (primer
areas**	application)
Standard absorbent (porous);	ARDEX P 51 1:1
warehouses and other non-	
aesthetic areas	

\*\*ARDEX EP 2000 and ARDEX MC RAPID are highly reactive epoxies that bond tenaciously to the substrate to minimize cracking in ARDEX toppings. Follow mixing and application instructions in the appropriate technical data sheet, including sand-broadcast to refusal.

### Step 2: Substrate Preparation (Proper Prep™)

For full details on Proper Prep, reference the following articles at <u>ardexamericas.com/services/properprep</u>:

- Article 1: Preparing Concrete for Bonded ARDEX or HENRY Applications
- Proper Prep Brochure

Mechanically prepare the substrate by shot blasting or similar means. Do not use acid etching, adhesive removers, solvents or sweeping compounds, as these are bond breakers. Sanding is not an effective method to remove contaminants from concrete.

Substrate must be dry and free of excess moisture and alkali. All substrates must be sound, solid and thoroughly clean of all bond-breaking contaminants, including but not limited to: overwatered or otherwise loose or weak material; dirt, dust, wax, grease, paints and oils; all curing compounds and sealers; and all adhesive residues. Following preparation, thoroughly vacuum to remove all excess dirt and debris.

Handle and dispose of asbestos and other hazardous materials in accordance with prevailing regulations, which supersede the recommendations in this document.

#### **Minimum Preparation**

In all cases, substrate must be clean; additional prep may be needed, as follows:

Substrate	Minimum Preparation
Concrete to receive ARDEX MC RAPID or ARDEX EP 2000	Mechanically remove all adhesive residue, sealers, curing compounds, tiles, mortars and epoxy coatings down to clean, sound, solid concrete / terrazzo
	Concrete and terrazzo substrates must be clean and prepared to a minimum CSP 3 / maximum CSP 5 (icri.org)
Concrete to receive ARDEX P 51	Substrate must be clean and absorbent (ASTM F3191)
Other approved, non- porous materials on concrete	Tile and terrazzo substrates must be abraded to facilitate bond.

### Step 3: Treating Joints and Cracks

Under no circumstances should any product herein be installed over joints (including control joints, expansion joints, isolation joints, etc.) or moving cracks. Honor all joints and moving cracks.

All dormant cracks greater than a hairline (1/32'') 0.8 mm) that will not be honored must be pre-filled with ARDEX ARDIFIX<sup>TM</sup> Low Viscosity Rigid Polyurethane Crack and Joint Repair and sand broadcasted to refusal in strict accordance with the technical data sheet.

The filling of dormant cracks as described above is recommended to help prevent the cracks from showing through the topping. However, should movement occur, cracks will reappear.

ARDEX cannot be responsible for problems that arise from joints, existing cracks or new cracks that may develop after the system has been installed.

### **Step 4: Install Appropriate Moisture Control or Priming Course**

Products may need longer drying times with low surface temperatures and/or high ambient humidity. Do not proceed with subsequent steps before product has dried thoroughly.

### ARDEX MC RAPID Installation (Priming course if moisture control is required)

If moisture control is required, install the ARDEX moisture control system in accordance with the appropriate technical data sheet (<u>www.ardexamericas.com/products</u>).

#### Priming (If moisture control is not required)

See section entitled Priming Method Selection above to select the appropriate primer based on the substrate.

#### Non-absorbent (non-porous; burnished) / Aesthetically critical areas: ARDEX EP 2000 or ARDEX MC RAPID (primer application)

Mix and apply the selected epoxy as directed in the technical data sheet. While the epoxy is fresh, immediately broadcast fine sand to refusal. Once the epoxy is cured, all excess sand must be collected and removed. Vacuum remaining sand using a heavy-duty, bucket-style (Shop-Vac-style) vacuum and HEPA dust extraction vacuum system.

### Standard absorbent (porous) Concrete (Where aesthetics are not critical): ARDEX P 51 1:1

Dilute primer with water at a rate of 1:1 by volume. Apply evenly with a clean, soft-bristled push broom. Do not use paint rollers, mops or spray equipment. Do not leave bare spots. Brush off puddles and excess primer.

It is critical to ensure that the primer is dry prior to proceeding with the next installation step. To determine if the primer is dry after a minimum of 30 minutes (max. 24 hours), pour water onto the surface of the primer in several areas and rub it with your finger. If the water remains clear, the primer is dry. If the water turns cloudy or milky, additional drying time is needed.

### Extremely absorbent concrete: ARDEX P 51 "Double prime"

Make an initial application of primer diluted with 3 parts water by volume. Let the initial application dry thoroughly (1 - 3 hours), and then install a second application of primer mixed 1:1 with water as detailed directly above

### Step 5: Mixing and Application

### **Recommended Tools**

ARDEX T-1 Mixing Paddle; Mixing Drum; 1/2" (12 mm) heavyduty drill (min. 650 rpm); appropriate measuring bucket; ARDEX T-4 Spreader; ARDEX T-5 Smoother; cleated athletic shoes with non-metallic spikes

#### Safety and OSHA Compliance

Handle each bag with care, emptying it in a manner that avoids creating a plume of dust. While mixing, use a standard "gutter hook" vacuum attachment in combination with a heavyduty, bucket-style vacuum (Shop-Vac or similar) and HEPA dust extraction vacuum system.

#### **Application Data**

Water Ratio:	/ater Ratio: 5 quarts (4.75 L) clean water Per bag	
Flow time:	10 minutes (70°F / 21°C)	

#### **Thickness of Application**

- 1/4" (6 mm) Average minimum thickness\*\*\*
- 2" (5 cm) Neat
- 5" (12.7 cm) with aggregate

\*\*\*1/8" minimum over highest point on the floor will typically result in average minimum thickness of at least 1/4".

### Manual

Mix two bags at a time. Pour the water in the mixing container first, and then add powder while mixing with the mixing paddle and a 1/2" (12 mm) heavy-duty drill (min. 650 rpm). Mix thoroughly for approximately 2 to 3 minutes to obtain a lump-free mix. Do not overwater! Additional water will weaken the compound and lower its strength. Yellowish foam while mixing, or settling of the sand aggregate while placing, indicates overwatering.

Pour the mix onto the floor. Spread with spreader. Immediately smooth the material with the smoother, or spike roll the material with the spiked roller. Work in a continuous manner during the entire self-leveling installation. Wear cleated athletic shoes with non-metallic spikes to avoid leaving marks in the liquid.

#### Aggregate Extension (as needed)

Extend the product with aggregate as desired / required (see "Thickness of Application" section above) as follows:

1. Select washed and well-graded pea gravel that is no larger than 1/3 the depth of the intended pour and no smaller than 1/8". Do not use sand.

2. Mix with water first, and then add 1 part by volume of the selected pea gravel, mixing until the aggregate is completely coated.

3. Note that the addition of aggregate will diminish the workability of the product and may make it necessary to install a neat coat.

If a neat coat is needed:

1. Allow the initial application to dry as detailed in "Drying Time" section below.

2. Prime the initial application with ARDEX P 51 mixed 1:1 (see "Priming" section above).

3. Install a neat coat as detailed above.

### Pumping

Product may be pumped using ARDIFLO<sup>™</sup> Automatic Mixing Pumps. ARDIFLO Pumps provide high productivity and smooth, consistent installations. Pumps may be rented from an authorized ARDEX Distributor. Please contact the ARDEX Technical Service Department with regard to pumping.

### Step 6: Drying and Sealing / Coating

Product must be sealed or coated with a material suitable for the intended operating conditions of the installation environment.

All dry times are calculated at 70°F (21°C). Drying time is a function of jobsite temperature and humidity conditions. Low substrate temperatures and/or high ambient humidity will extend the drying time. Adequate ventilation and heat will aid drying. Forced drying can dry the surface of the product prematurely and is not recommended.

High-build coatings at 1/8" or greater	7 days; Shot blast and deep vacuum the surface prior to coating application
Any coating at a thickness exceeding 20 mils	3 - 5 days
Solvent-borne or 100% solids coating at a thickness up to 20 mils	24 hours
ARDEX CG or other waterborne sealer at a thickness up to 20 mils: Walkable	When hardened and dried to a uniform tonality (Typically 2 - 3 hours)

### Cracking

This product and other, similar thinly applied non-structural toppings are not capable of restraining movement in the structural slab, which could lead to reflective cracking. Telegraphing is common where there is slab deflection, vibration from truck traffic and/or subways, swaying or "racking" of high rise buildings, existing cracks or joints in the slab and/or electrical boxes, vents or other metal inserts. While priming with ARDEX EP 2000 is the best way to minimize the possibility of reflective cracking, cracks may telegraph up into the surface in any area that exhibits movement.

Additionally, certain jobsite conditions can lead to hairline cracking. Hairline cracking, while aesthetically unpleasant, typically does not affect the overall performance of the topping. The most common cause of hairline cracking is excessively rapid moisture evaporation from the topping during cure due to low ambient humidity and/or rapid air movement in the space. Hairline cracking can also occur when there is even slight movement or deflection in the existing substrate.

If cracking occurs, we recommend sounding the affected areas to ensure that the topping is well-bonded to the substrate.

### Step 7: Care and Maintenance of ARDEX Surfaces

Follow the care and maintenance instructions specified by the manufacturer of the selected wear protection system.

### Notes

Intended for use by professional contractors who are trained in the application of this product and/or similar products. Not sold by ARDEX through home improvement centers. For information on ARDEX Academy trainings, visit: <u>www.ardexamericas.com</u>. Never mix with cement or additives outside of our written recommendations. In accordance with industry standards, and to determine the suitability of the products for the intended use, always install an adequate number of properly located test areas including the sealer / coating. As finish materials vary, always contact and rely upon the sealer / coating manufacturer for specific directives, such as maximum allowable moisture content and intended end use of the product.

Observe the basic rules of concrete work, including the minimum surface and air temperatures detailed above. Install quickly if the substrate is warm, and follow the warm weather installation guidelines available on our website.

Dispose of packaging and residue in accordance with prevailing regulations. Do not flush material down drains. Do not reuse packaging.

### Precautions

Carefully read and follow all precautions and warnings on the product label. For complete safety information, please refer to the Safety Data Sheet (SDS) available at:

www.ardexamericas.com.

### **Technical Data According to Manufacturer Quality Standards**

Physical properties are typical values and not specifications. All data based on a partial, in-lab mix. Testing completed at  $70^{\circ}F/21^{\circ}C$ .

Compressive	6,100 psi (428 kg/cm <sup>2</sup> ); 28 days	
Strength (ASTM		
C109/mod – Air		
cure only):		
Flexural	1,200 psi (84 kg/cm <sup>2</sup> ); 28 days	
Strength (ASTM		
C348) (ASTM		
C348):		
Coverage:	Per bag At 1/4" (6 mm): 25 sq. ft. (2.3 sq. m)	
	Per bag At 1/2" (12 mm): 12.5 sq. ft. (1.2	
	sq. m)	
	Dependent on surface profile, density and	
	porosity.	
Drying Time:	See section entitled Drying and Sealing / Coating	
VOC:	0	
Packaging:	50 lb. (22.7 kg) bag	
Colors:	Gray and White	
Storage:	Store in a cool, dry area. Do not leave units	
	exposed to sun.	
Shelf Life:	9 months, if unopened and properly stored	
Warranty:	ARDEX L.P. Standard Limited Warranty	
-	applies. For full warranty details:	
	ardexamericas.com/services/warranties.	

Made in the USA.

Copyright 2023 ARDEX, L.P. All rights reserved. Content updated 2023-02-28. Supersedes all previous versions. Latest version available at:

www.ardexamericas.com.

Visit www.youtube.com/ARDEX101 to watch ARDEX product demonstration videos. For recommended installation tools, visit DTA USA at www.dtausagroup.com. For easy-to-use ARDEX Product Calculators and Product Information On the Go, download the ARDEX App.







ARDEX Americas 400 Ardex Park Drive Aliquippa, PA 15001 USA 888-512-7339 www.ardexamericas.com