

# GEOFOAM LOAD EXAMPLE 1

## APPLICABLE TO ATLAS GEOFOAM

### INTRODUCTION

Atlas Geofoam is used in a wide range of structural and civil engineering applications. The selection of the appropriate grade of geofoam for a specific application is a critical decision to ensure suitable long term performance.

Atlas Geofoam is a lightweight fill produced in compliance with ASTM D6817, “Standard Specification for Rigid Polystyrene Geofoam”. Atlas Geofoam is available in 7 standard grades with compressive resistance @1 % strain ranging from 320 to 2,680 psf where the compressive resistance at 1% is the industry accepted allowable stress for the combination of dead and live loads for geofoam.

### DISCLAIMER

This geofoam load calculation example is being provided to illustrate a simplified method for the calculation of vertical stress on Atlas Geofoam in a hypothetical example. This simplified method is being provided only as an example and should not be relied upon for the selection of geofoam for a particular project. In applications where a concrete load distribution slab is used above the geofoam, more advanced load distribution analysis methods such as finite element modeling are recommended.

The selection and/or specification of a geofoam grade for a specific application should be determined by a qualified civil engineer who is acquainted with all possible aspects of a particular project.

### EXAMPLE

A project is proposed to be built using geofoam with a cross section and load as shown in Figure 1. Atlas Geofoam EPS 22 is proposed to be used. Vertical loads must be calculated to ensure EPS 22 is appropriate.




Figure 1. Project Section

## ANALYSIS METHOD

A simplified vertical stress distribution model is shown in Figure 2 based on NCHRP published literature<sup>1</sup>.

### LOAD DISTRIBUTION




Figure 2. Simplified vertical stress distribution

$Q$  = loading

$B$  = equivalent width of loading

$\theta_1$  = 1H:1V slope

$\theta_2$  = 1H:2V slope

$\theta_3$  = 1H:2V slope

$z_1$  = thickness of pavement

$z_2$  = thickness of base

$z_3$  = depth within geofoam

$L_{TG}$  = width of load at top of geofoam

$L_{BG}$  = width of load at bottom of geofoam

## Reference

<sup>1</sup> NCHRP Web Document 65 (Project 24-11) Geofoam Applications in Design and Construction of Highway Embankments, National Cooperative Highway Research Program, July 2004

## CALCULATION – DEAD LOADS




Figure 3. Calculations for dead loads

Dead load at top of geofoam:

$$\sigma_{DLTG} = z_1 * \gamma_{Pavement} + z_2 * \gamma_{Base}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  = unit weight of pavement and base, respectively

$$\sigma_{DLTG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 = 425 \text{ lbs/ft}^2$$

$$\sigma_{DLTG} = (425 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 2.95 \text{ psi}$$

Dead load at bottom of geofoam:

$$\sigma_{DLBG} = z_1 * \gamma_{Pavement} + z_2 * \gamma_{Base} + z_{GEOFOAM} * \gamma_{GEOFOAM}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  and  $\gamma_{GEOFOAM}$  = unit weight of pavement, base, and geofoam, respectively

$$\sigma_{DLBG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 + 6 \text{ ft} * 1.35 \text{ lbs/ft}^3 = 433 \text{ lbs/ft}^2$$

$$\sigma_{DLBG} = (433 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.01 \text{ psi}$$

## CALCULATION – LIVE LOAD WIDTH




Figure 4. Calculations for live loads

Live load width at top of geofoam:

$$L_{TG} = B + 2z_1 + z_2$$

$$L_{TG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} = 5 \text{ ft}$$

Live load width at bottom of geofoam:

$$L_{BG} = B + 2z_1 + z_2 + z_3$$

$$L_{BG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 6 \text{ ft} = 11 \text{ ft}$$

Note: Loads are shown calculated at top and bottom of geofoam only here for simplicity, but the load at any depth in geofoam can be calculated following a similar method.

## CALCULATION – LIVE LOADS

Live load at top of geofoam:

$$\sigma_{LLTG} = Q / (L_{TG} * L_{TG})$$

$$\sigma_{LLTG} = 12500 \text{ lb} / (5 \text{ ft} * 5 \text{ ft}) = 500 \text{ lb/ft}^2$$

$$\sigma_{LLTG} = (500 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.47 \text{ psi}$$

Live load at bottom of geofoam:

$$\sigma_{LLBG} = Q / (L_{BG} * L_{BG})$$

$$\sigma_{LLBG} = 12500 \text{ lb} / (11 \text{ ft} * 11 \text{ ft}) = 103 \text{ lb/ft}^2$$

$$\sigma_{LLBG} = (103 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 0.72 \text{ psi}$$

## Calculation – Total Dead Loads and Live Loads

Total load at top of geofoam:

$$\sigma_{TLTG} = \sigma_{DLTG} + \sigma_{LLTG}$$

$$\sigma_{TLTG} = 425 \text{ lb/ft}^2 + 500 \text{ lb/ft}^2 = 925 \text{ lb/ft}^2$$

$$\sigma_{TLTG} = 2.95 \text{ psi} + 3.47 \text{ psi} = 6.42 \text{ psi}$$

Total load at bottom of geofoam:

$$\sigma_{TLBG} = \sigma_{DLBG} + \sigma_{LLBG}$$

$$\sigma_{TLBG} = 433 \text{ lb/ft}^2 + 103 \text{ lb/ft}^2 = 536 \text{ lb/ft}^2$$

$$\sigma_{TLBG} = 3.01 \text{ psi} + 0.72 \text{ psi} = 3.73 \text{ psi}$$

Maximum stress on geofoam is 6.42 psi

EPS 22 with a compressive resistance at 1% strain of 7.3 psi is suitable for loads provided in this example.

VISIT **ATLASMOLDEDPRODUCTS.COM** FOR THE LATEST TECHNICAL INFORMATION

**GREATER COVERAGE  
GREATER AVAILABILITY**



Atlas Molded Products, a Division of Atlas Roofing Corporation

8700 Turnpike Drive, Suite 400, Westminster, CO 80031

Phone: 855.597.4427 | Fax: 303.428.2595 | AMPinfo@AtlasRoofing.com



# GEOFOAM LOAD EXAMPLE 2

## APPLICABLE TO ATLAS GEOFOAM

### INTRODUCTION

Atlas Geofoam is used in a wide range of structural and civil engineering applications. The selection of the appropriate grade of geofoam for a specific application is a critical decision to ensure suitable long term performance.

Atlas Geofoam is a lightweight fill produced in compliance with ASTM D6817, “Standard Specification for Rigid Polystyrene Geofoam”. Atlas Geofoam is available in 7 standard grades with compressive resistance @1 % strain ranging from 320 to 2,680 psf where the compressive resistance at 1% is the industry accepted allowable stress for the combination of dead and live loads for geofoam.

### DISCLAIMER

This geofoam load calculation example is being provided to illustrate a simplified method for the calculation of vertical stress on Atlas Geofoam in a hypothetical example. This simplified method is being provided only as an example and should not be relied upon for the selection of geofoam for a particular project. In applications where a concrete load distribution slab is used above the geofoam, more advanced load distribution analysis methods such as finite element modeling are recommended.

The selection and/or specification of a geofoam grade for a specific application should be determined by a qualified civil engineer who is acquainted with all possible aspects of a particular project.

### EXAMPLE

A project is proposed to be built using geofoam with a cross section and loads as shown in Figure 1. Atlas Geofoam EPS 22 is proposed to be used. Vertical loads must be calculated to ensure EPS 22 is appropriate.




Figure 1. Project Section



## ANALYSIS METHOD

A simplified vertical stress distribution model is shown in Figure 2 and Figure 3 based on NCHRP published literature<sup>1</sup>.

### TRANSVERSE LOAD DISTRIBUTION




Figure 2. Simplified vertical stress distribution

### LONGITUDINAL LOAD DISTRIBUTION




Figure 3. Simplified vertical stress distribution

$Q$  = loading

$B$  = equivalent width of loading in the transverse or longitudinal direction

$S$  = spacing between inside edge of equivalent width of loading

$\theta_1$  = 1H:1V slope

$\theta_2$  = 1H:2V slope

$\theta_3$  = 1H:2V slope

$z_1$  = thickness of pavement

$z_2$  = thickness of road base

$z_3$  = depth within geofoam

$z_4$  = depth within geofoam

## Reference

<sup>1</sup> NCHRP Web Document 65 (Project 24-11) Geofoam Applications in Design and Construction of Highway Embankments, National Cooperative Highway Research Program, July 2004

## CALCULATION – DEAD LOADS



Figure 4. Calculations for dead loads

Dead load at top of geofoam:

$$\sigma_{DLTG} = Z_1 * \gamma_{Pavement} + Z_2 * \gamma_{Base}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  = unit weight of pavement and base, respectively

$$\sigma_{DLTG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 = 425 \text{ lbs/ft}^2$$

$$\sigma_{DLTG} = (425 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 2.95 \text{ psi}$$

Dead load at beginning of overlap depth of geofoam: (see Figure 5)

$$\sigma_{DLOD} = Z_1 * \gamma_{Pavement} + Z_2 * \gamma_{Base} + Z_{GEOFOAM} * \gamma_{GEOFOAM}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  and  $\gamma_{GEOFOAM}$  = unit weight of pavement, base, and geofoam, respectively

$$\sigma_{DLOD} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 + 1 \text{ ft} * 1.35 \text{ lbs/ft}^3 = 426 \text{ lbs/ft}^2$$

$$\sigma_{DLOD} = (426 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 2.96 \text{ psi}$$

Dead load at bottom of geofoam:

$$\sigma_{DLBG} = Z_1 * \gamma_{Pavement} + Z_2 * \gamma_{Base} + Z_{GEOFOAM} * \gamma_{GEOFOAM}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  and  $\gamma_{GEOFOAM}$  = unit weight of pavement, base, and geofoam, respectively

$$\sigma_{DLBG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 + 6 \text{ ft} * 1.35 \text{ lbs/ft}^3 = 433 \text{ lbs/ft}^2$$

$$\sigma_{DLBG} = (433 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.01 \text{ psi}$$



## CALCULATION – LIVE LOAD WIDTH TRANSVERSE




Figure 5. Calculations for live loads

Live load width at top of geofoam:

$$L_{TG} = B + 2z_1 + z_2$$

$$L_{TG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} = 5 \text{ ft}$$

Live load width at beginning of overlap depth of vertical stress distributions from 2 transverse surface loads

$$L_{OD} = 2B + S + 2z_1 + z_2 + z_3$$

$$L_{OD} = 2 * 1 \text{ ft} + 5 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 1 \text{ ft} = 12 \text{ ft}$$

Live load width at bottom of geofoam:

$$L_{BG} = 2B + S + 2z_1 + z_2 + z_3 + z_4$$

$$L_{BG} = 2 * 1 \text{ ft} + 5 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 1 \text{ ft} + 5 \text{ ft} = 17 \text{ ft}$$

Note: Loads are shown calculated at top, beginning of overlap, and bottom of geofoam only here for simplicity, but the load at any depth in geofoam can be calculated following a similar method.

## CALCULATION – LIVE LOAD WIDTH LONGITUDINAL




Figure 6. Calculations for live loads

Live load width at top of geofoam:

$$L_{TG} = B + 2z_1 + z_2$$

$$L_{TG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} = 5 \text{ ft}$$

Live load width at bottom of geofoam:

$$L_{BG} = B + 2z_1 + z_2 + z_3$$

$$L_{BG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 6 \text{ ft} = 11 \text{ ft}$$

Note: Loads are shown calculated at top and bottom of geofoam only here for simplicity, but the load at any depth in geofoam can be calculated following a similar method.

## CALCULATION – LIVE LOADS

Live load at top of geofoam:

No load interaction so load = Q

$$\sigma_{LL\,TG} = Q / (L_{TG\,TR} * L_{TG\,LO})$$

$$\sigma_{LL\,TG} = 12500 \text{ lb} / (5 \text{ ft} * 5 \text{ ft}) = 500 \text{ lb/ft}^2$$

$$\sigma_{LL\,TG} = (500 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.47 \text{ psi}$$

Live load at beginning of stress overlap depth of geofoam:

Two loads interact so load = 2Q

$$\sigma_{LL\,OD} = 2Q / (L_{OD\,TR} * L_{OD\,LO})$$

$$\sigma_{LL\,OD} = 2 * 12500 \text{ lb} / (12 \text{ ft} * 6 \text{ ft}) = 347 \text{ lb/ft}^2$$

$$\sigma_{LL\,OD} = (347 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 2.41 \text{ psi}$$

Live load at bottom of geofoam:

$$\sigma_{LL\,BG} = 2Q / (L_{BG\,TR} * L_{BG\,LO})$$

$$\sigma_{LL\,BG} = 2 * 12500 \text{ lb} / (17 \text{ ft} * 11 \text{ ft}) = 134 \text{ lb/ft}^2$$

$$\sigma_{LL\,BG} = (134 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 0.93 \text{ psi}$$

## Calculation – Total Dead Loads and Live Loads

Total load at top of geofoam:

$$\sigma_{TL\,TG} = \sigma_{DL\,TG} + \sigma_{LL\,TG}$$

$$\sigma_{TL\,TG} = 425 \text{ lb/ft}^2 + 500 \text{ lb/ft}^2 = 925 \text{ lb/ft}^2$$

$$\sigma_{TL\,TG} = 2.95 \text{ psi} + 3.47 \text{ psi} = 6.42 \text{ psi}$$

Total load at beginning of stress overlap depth of geofoam:

$$\sigma_{TL\,OD} = \sigma_{DL\,OD} + \sigma_{LL\,OD}$$

$$\sigma_{TL\,OD} = 426 \text{ lb/ft}^2 + 347 \text{ lb/ft}^2 = 773 \text{ lb/ft}^2$$

$$\sigma_{TL\,OD} = 2.96 \text{ psi} + 2.41 \text{ psi} = 5.37 \text{ psi}$$

Total load at bottom of geofoam:

$$\sigma_{TL\,BG} = \sigma_{DL\,BG} + \sigma_{LL\,BG}$$

$$\sigma_{TL\,BG} = 433 \text{ lb/ft}^2 + 134 \text{ lb/ft}^2 = 567 \text{ lb/ft}^2$$

$$\sigma_{TL\,BG} = 3.01 \text{ psi} + 0.93 \text{ psi} = 3.94 \text{ psi}$$

Maximum stress on geofoam is 6.42 psi

EPS 22 with a compressive resistance at 1% strain of 7.3 psi is suitable for the loads provided in this example.

**VISIT [ATLASMOLDEDPRODUCTS.COM](https://atlasroofing.com) FOR THE LATEST TECHNICAL INFORMATION**

**GREATER COVERAGE  
GREATER AVAILABILITY**



**Atlas Molded Products, a Division of Atlas Roofing Corporation**

8700 Turnpike Drive, Suite 400, Westminster, CO 80031

Phone: 855.597.4427 | Fax: 303.428.2595 | [AMPinfo@AtlasRoofing.com](mailto:AMPinfo@AtlasRoofing.com)



# GEOFOAM LOAD EXAMPLE 3

## APPLICABLE TO ATLAS GEOFOAM

### INTRODUCTION

Atlas Geofoam is used in a wide range of structural and civil engineering applications. The selection of the appropriate grade of geofoam for a specific application is a critical decision to ensure suitable long term performance.

Atlas Geofoam is a lightweight fill produced in compliance with ASTM D6817, "Standard Specification for Rigid Polystyrene Geofoam". Atlas Geofoam is available in 7 standard grades with compressive resistance @1 % strain ranging from 320 to 2,680 psf where the compressive resistance at 1% is the industry accepted allowable stress for the combination of dead and live loads for geofoam.

### DISCLAIMER

This geofoam load calculation example is being provided to illustrate a simplified method for the calculation of vertical stress on Atlas Geofoam in a hypothetical example. This simplified method is being provided only as an example and should not be relied upon for the selection of geofoam for a particular project. In applications where a concrete load distribution slab is used above the geofoam, more advanced load distribution analysis methods such as finite element modeling are recommended.

The selection and/or specification of a geofoam grade for a specific application should be determined by a qualified civil engineer who is acquainted with all possible aspects of a particular project.

### EXAMPLE

A project is proposed to be built using geofoam with a cross section and loads as shown in Figure 1. Atlas Geofoam EPS 22 is proposed to be used. Vertical loads must be calculated to ensure EPS 22 is appropriate.




Figure 1. Project Section

## ANALYSIS METHOD

A simplified vertical stress distribution model is shown in Figure 2 based on NCHRP published literature<sup>1</sup>.

### LOAD DISTRIBUTION




Figure 2. Simplified vertical stress distribution

$Q$  = loading

$B$  = equivalent width of loading in the transverse or longitudinal direction

$S$  = spacing between inside edge of equivalent width of loading

$\theta_1$  = 1H:1V slope

$\theta_2$  = 1H:2V slope

$\theta_3$  = 1H:2V slope

$z_1$  = thickness of pavement

$z_2$  = thickness of road base

$z_3$  = depth within geofoam

$z_4$  = depth within geofoam

## Reference

<sup>1</sup> NCHRP Web Document 65 (Project 24-11) Geofoam Applications in Design and Construction of Highway Embankments, National Cooperative Highway Research Program, July 2004

## CALCULATION – DEAD LOADS




Figure 3. Calculations for dead loads

Dead load at top of geofoam:

$$\sigma_{DLTG} = z_1 * \gamma_{Pavement} + z_2 * \gamma_{Base}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  = unit weight of pavement and base, respectively

$$\sigma_{DLTG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 = 425 \text{ lbs/ft}^2$$

$$\sigma_{DLTG} = (425 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 2.95 \text{ psi}$$

Dead load at bottom of geofoam:

$$\sigma_{DLBG} = z_1 * \gamma_{Pavement} + z_2 * \gamma_{Base} + z_{GEOFOAM} * \gamma_{GEOFOAM}$$

where  $\gamma_{Pavement}$  and  $\gamma_{Base}$  and  $\gamma_{GEOFOAM}$  = unit weight of pavement, base, and geofoam, respectively

$$\sigma_{DLBG} = 1 \text{ ft} * 145 \text{ lbs/ft}^3 + 2 \text{ ft} * 140 \text{ lbs/ft}^3 + 6 \text{ ft} * 1.35 \text{ lbs/ft}^3 = 433 \text{ lbs/ft}^2$$

$$\sigma_{DLBG} = (433 \text{ lbs/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.01 \text{ psi}$$



# CALCULATION – LIVE LOAD WIDTH TRANSVERSE




Figure 4. Calculations for live loads

Live load width at top of geofoam:

$$L_{TG} = B + 2z_1 + z_2$$

$$L_{TG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} = 5 \text{ ft}$$

Live load width at bottom of geofoam:

$$L_{BG} = 2B + S + 2z_1 + z_2 + z_3 + z_4$$

$$L_{BG} = 2 * 1 \text{ ft} + 5 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 1 \text{ ft} + 5 \text{ ft} = 17 \text{ ft}$$

Note: Loads are shown calculated at top and bottom of geofoam only here for simplicity, but the load at any depth in geofoam can be calculated following a similar method.

# CALCULATION – LIVE LOAD WIDTH LONGITUDINAL




Figure 5. Calculations for live loads

Live load width at top of geofoam:

$$L_{TG} = B + 2z_1 + z_2$$

$$L_{TG} = 1 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} = 5 \text{ ft}$$

Live load width at bottom of geofoam:

$$L_{BG} = 2B + S + 2z_1 + z_2 + z_3 + z_4$$

$$L_{BG} = 2 * 1 \text{ ft} + 4 \text{ ft} + 2 * 1 \text{ ft} + 2 \text{ ft} + 0 \text{ ft} + 6 \text{ ft} = 16 \text{ ft}$$

Note: Loads are shown calculated at top and bottom of geofoam only here for simplicity, but the load at any depth in geofoam can be calculated following a similar method.

## CALCULATION – LIVE LOADS

Live load at top of geofoam:

No load interaction so load = Q

$$\sigma_{LLTG} = Q / (L_{TGTR} * L_{TGLo})$$

$$\sigma_{LLTG} = 12500 \text{ lb} / (5 \text{ ft} * 5 \text{ ft}) = 500 \text{ lb/ft}^2$$

$$\sigma_{LLTG} = (500 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 3.47 \text{ psi}$$

Live load at bottom of geofoam:

All four loads interact so load = 4Q

$$\sigma_{LLBG} = 4Q / (L_{BGTR} * L_{BGLo})$$

$$\sigma_{LLBG} = 4 * 12500 \text{ lb} / (17 \text{ ft} * 16 \text{ ft}) = 184 \text{ lb/ft}^2$$

$$\sigma_{LLBG} = (184 \text{ lb/ft}^2) / (144 \text{ in}^2/\text{ft}^2) = 1.28 \text{ psi}$$

## Calculation – Total Dead Loads and Live Loads

Total load at top of geofoam:

$$\sigma_{TLTG} = \sigma_{DLTG} + \sigma_{LLTG}$$

$$\sigma_{TLTG} = 425 \text{ lb/ft}^2 + 500 \text{ lb/ft}^2 = 925 \text{ lb/ft}^2$$

$$\sigma_{TLTG} = 2.95 \text{ psi} + 3.47 \text{ psi} = 6.42 \text{ psi}$$

Total load at bottom of geofoam:

$$\sigma_{TLBG} = \sigma_{DLBG} + \sigma_{LLBG}$$

$$\sigma_{TLBG} = 433 \text{ lb/ft}^2 + 184 \text{ lb/ft}^2 = 617 \text{ lb/ft}^2$$

$$\sigma_{TLBG} = 3.01 \text{ psi} + 1.28 \text{ psi} = 4.29 \text{ psi}$$

Maximum stress on geofoam is 6.42 psi

EPS 22 with a compressive resistance at 1% strain of 7.3 psi is suitable for the loads provided in this example.

VISIT **ATLASMOLDEDPRODUCTS.COM** FOR THE LATEST TECHNICAL INFORMATION

**GREATER COVERAGE  
GREATER AVAILABILITY**



Atlas Molded Products, a Division of Atlas Roofing Corporation

8700 Turnpike Drive, Suite 400, Westminster, CO 80031

Phone: 855.597.4427 | Fax: 303.428.2595 | AMPinfo@AtlasRoofing.com

