

# Sure-White® EPDM

## Pressure-Sensitive Curb Flashing



### Overview

Carlisle's 20"-wide Sure-White EPDM Pressure-Sensitive Curb Flashing comes with factory-applied 6" SecurTAPE™ and provides the most efficient means to flash a curb. Production time on projects with numerous curbs or wall flashings can be substantially reduced with this labor-saving accessory.

### Features and Benefits

- » Available in 20" x 50' rolls
- » Pre-cut 20"-wide cured 60-mil EPDM Flashing with factory-applied 6" SecurTAPE
- » Provides up to 70% labor savings for flashing curbs and walls
- » Provides a cleaner appearance and stronger seams
- » Approved for use with Carlisle's Sure-White EPDM and Sure-Weld® TPO membranes

### Installation

1. Attach deck membrane at the curb according to Carlisle details.
2. Cut a piece of PS Curb Flashing equal in length to the perimeter of the curb plus 3" minimum (e.g. a 2' x 2' curb would require an 8'-3" length of PS Curb Flashing).
3. Cut the width of the PS Curb Flashing to match the height of the curb plus 6" for the splice and 2" to go over the top of the curb. (Width = curb height + 8".)
4. The entire surface against which the PS Curb Flashing will be applied must be clean. The adhesive on the back of the PS Curb Flashing will not adhere to dusted or dirty surfaces. Any residual contamination will be detrimental to the bond strength of the adhesive.
5. Remove all foreign material.
  - a. Remove excess mica dust by brooming or wiping with a clean, dry rag or Carlisle HP Splice Wipe.
  - b. The use of Weathered Membrane Cleaner may be necessary. This process is essential on membrane that has been exposed for a number of weeks.
 

*Note: Permeation-resistant gloves (that meet ANSI/ISEA 105-2005) are required for hand protection when cleaners or primers are being used.*
  - c. Allow the membrane to dry thoroughly before proceeding.
6. Place the PS Curb Flashing on a flat surface with the tape side up and the release liner intact.
7. Apply Carlisle Bonding Adhesive to the curb and to the PS Curb Flashing.
8. After the Bonding Adhesive has flashed off properly, bond the PS Curb Flashing to the curb. Wrap the entire curb, leaving the area containing the tape adhesive folded upwards with release liner still in place. Take care not to stretch the PS Curb Flashing.
9. Membrane type determines which primer to use. HP-250 Primer is used with EPDM membranes, TPO Primer is used with TPO membranes, and Low-VOC Primer can be used with TPO and EPDM membranes.
10. Apply HP-250 Primer, TPO Primer, or Low-VOC Primer and allow to flash off properly.
11. To complete the splice between the PS Curb Flashing and the deck membrane, cut the PS Curb Flashing at each corner of the curb, allowing the PS Curb Flashing to fall in place. Round all cut corners. Press the PS Curb Flashing into the angle change as tightly as possible.
12. With the tape adhesive lying flat on the primed surface, remove the release liner by pulling it out from beneath the PS Curb Flashing. Simultaneously, press the tape onto the primed surface using firm, even hand pressure across the splice toward the splice edge. Immediately roll the splice with a 2"-wide roller, using positive pressure.
13. Broom the PS Curb Flashing over the curb to ensure proper mating of the bonding adhesive.

# Sure-White EPDM

## Pressure-Sensitive Curb Flashing

14. Make the vertical splice in the PS Curb Flashing as per Carlisle U-2A details.
15. Flash the corners of the curb as per Carlisle U-15 details.

*Review Carlisle specifications and details for complete installation information.*

### Precautions

- » Avoid prolonged contact with skin. In case of contact with skin, thoroughly wash affected area with soap and water.
- » Carlisle Bonding Adhesive and EPDM, TPO, or Low-VOC Primer must be used when installing PS Curb Flashing.
- » PS Curb Flashing must be stored in a dry area. In warm, sunny weather, keep PS Curb Flashing in the box in a shaded area until ready to use.
- » Due to solvent flash-off, condensation may form on freshly applied primer when the ambient temperature is near the dew point. If condensation develops, discontinue the application of primer and installation of PS Curb Flashing, as proper adhesion will not be achieved. Allow the primed surface to dry and apply a thin fresh coat of primer to the previously coated surface when conditions allow.
- » Jobsite storage temperatures higher than 90°F (32°C) will shorten the product's shelf life. Prolonged jobsite exposure to temperatures below 40°F (4°C) will cause the adhesive to lose tack and, in extreme cases, not bond to the membrane. If this occurs, move PS Curb Flashing to a warm area and allow it to return to a minimum of 60°F (15°C).
- » To achieve proper adhesion to the deck membrane when installing PS Curb Flashing at temperatures below 40°F (5°C), heat the primed area of the deck membrane with a hot-air gun as the tape adhesive is applied and pressed into place.
- » Do not allow waste products (petroleum, grease, oil, solvents, vegetable or mineral oil, animal fats, etc.) or direct steam venting to come in contact with the PS Curb Flashing.
- » KEEP OUT OF THE REACH OF CHILDREN.

### Typical Properties and Characteristics

Base	Membrane-EPDM Adhesive-Synthetic Rubber
Thickness	Membrane - 60-mil (1.52 mm)
Size	20" x 50' (508 mm x 15.2 m)
Packaging	50 lf/carton (15.2 m) - 1 roll/carton
Weight/Carton	30 lbs (14 Kg)
Shelf Life	1 year

Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.

### LEED® Information

Pre-consumer Recycled Content	0%
Post-consumer Recycled Content	0%
Manufacturing Location	Carlisle, PA
Solar Reflectance Index	94