


Technical Information Sheet



RubberGard™ EPDM SA

Item Description	Item Number
.060" x 10' x 100' (1.52 mm x 3.05 m x 30.5 m)	W56L61010SA

Description

Elevate RubberGard EPDM SA membrane with Secure Bond™ Technology is designed to be the next generation of self-adhered roof system application. Secure Bond Technology is factory applied which helps ensure uniform adhesion across the entire membrane, creating a powerful bond with the substrate. This advanced technology not only improves installation speed over traditional fully adhered applications, but also widens the installation window with the ability to be installed down to 20 °F (-7 °C). With no VOCs, RubberGard EPDM SA with Secure Bond Technology is an excellent solution for all your fully adhered roofing needs.

RubberGard EPDM SA membrane meets or exceeds all the requirements for ASTM D 4637 for Type I non-reinforced EPDM single-ply roofing membranes.

Membrane Preparation

1. Substrates must be clean, dry, and free of foreign material such as grease and any debris which could inhibit adhesion. This may require cleaning with a broom or blower.
2. Fasten insulation per current Holcim technical specifications to provide a proper substrate.
3. Install RubberGard EPDM SA membrane only when ambient and substrate temperatures are minimum 20 °F (-7 °C) and rising. Do not install RubberGard EPDM SA below this minimum temperature.
4. Apply Single-Ply QuickPrime Primer, Single-Ply LVOC Primer or Elevate Jet Bond Membrane Adhesive to vertical surfaces before installing flashing membrane.
5. Unroll and position the membrane over the substrate to achieve the desired alignment and overlaps. Allow membrane to relax before positioning and adhering. **NOTE: Once the membrane has fully relaxed, follow field membrane and roof edge membrane application methods below to adhere the membrane to the approved substrate.**

Method of Application

Field Membrane Application (Steps 1-5):

1. Once the membrane has relaxed in place a minimum of 30 minutes (longer in colder weather), and the seam positions are properly aligned, carefully fold back the leading edge of the membrane at one end to expose the release liner without disturbing the original position of the membrane.

Field Membrane Application (Steps 1-5) Continued:

2. Starting from the center split of the exposed release liner, remove the liner on both sides of the split at a 45° angle back beyond the membrane edge, making sure to pull enough of the release liner to hold below the membrane. Remove approximately 5' (1.5 m) of release liner from one end of the sheet and adhere the membrane to the substrate. The release liner removed should be enough to extend out beyond both edges of the membrane.
NOTE: Do not fold the length of the roll in half.
3. Keeping the membrane flat and secured, and the seam overlap aligned, continue removing the release liner at a 45° angle along the entire length of the entire sheet (up to 100'). Pulling the release liner at a higher angle can cause the sheet to move and may trap air. The two halves of the release liner should be pulled out at the same time by two people. Keep the release liner as close to the roof surface as possible during removal. **NOTE: Removal of the liner and any handling of the exposed SA adhesive should be done by two persons minimum.**
4. To initiate adhesion, use a stiff bristled broom and apply downward pressure across the width of the sheet working toward the sheet edge. Repeat the process for the other half of the membrane by starting from the center and brooming toward the sheet edge.
5. Roll the installed membrane with a weighted roller (5 lb per lineal inch) across the width of the membrane to ensure full contact with the substrate. **NOTE: Do not roll membrane in place with a weighted roller if installed over ISOGARD™ HD or Resista™ / ISOGARD CG.**

Application Information – Jet Bond Adhesive Used as Primer on Vertical Surfaces:

1. Apply Jet Bond Adhesive in a one-side (substrate only) primer application using a coverage rate of 2,000 square feet (20 square) per canister.
2. Pattern application shall be two back and forth overlapping passes to ensure full coverage.
3. Allow adhesive to flash off before mating the self-adhered membrane.

Seaming

NOTE: It is very important that both surfaces are clean, and no moisture is present on the splicing surfaces.

1. Side Laps - Fold back the membrane at the side lap to expose the unadhered selvedge edge of the top sheet and the bottom surface of the field seam. Prime the area to receive QuickSeam™ 3" (76 mm) Splice Tape with an approved Elevate primer per current specifications. Use the touch/push test to verify the primer has flashed off then apply the QuickSeam tape per Elevate "QuickSeam Splice Tape Application Instructions".
2. End Laps – Because the Secure Bond Adhesive extends the entire length of the roll, adjoining end laps must be stripped in. Prime and overlap the butt ends of EPDM SA membrane a minimum of 3" (76 mm). Apply additional primer 4" (102 mm) to either side of the overlap. After the primer has flashed off, strip in the entire end lap with 6" (152 mm) Batten Cover Strip.
3. Detailing - Install t-joint patches at all Batten Cover Strip overlaps, tape laps, etc., and apply a bead of Lap sealant as required by current Holcim specifications.

Storage

- Warehouse membrane in a clean dry location.
- Membrane that is stored on jobsite must be kept dry.
- Material must be a minimum of 20 °F (-7 °C) prior to installation.
- Store away from sources of punctures and physical damage.
- Make certain the structural decking will support the loads incurred by material when stored on rooftop. The deck load limitations should be specified by the project designer.
- Store away from ignition sources.

Shelf Life

18 Months when stored between 60 °F (16 °C) and 80 °F (27 °C) out of direct sunlight.

Precautions

- Take care when moving, transporting, and handling to avoid sources of punctures and physical damage.
- Removal of the plastic release liner from the adhesive backing may create a static electric charge; care should be used when removing and handling the release liner.
- Refer to Safety Data Sheets (SDS) for additional safety information.

LEED® Information

Post-Consumer Recycled Content: 0%
 Post Industrial Recycled Content: 3-5%
 Manufacturing Location: Tuscumbia, AL

NOTE: LEED® is a registered trademark of the U.S. Green Building Council



Typical Properties – Secure Bond Pressure Sensitive Adhesives			
Property	Test Method	Performance Minimum	Typical Performance
Color	---	---	Clear
Nominal Thickness	ASTM E 408-71	N/A	0.007 in (0.180 mm)
Weight	---	---	0.040 lb/ft ² (0.002 kg/m ²)

Typical Properties			
Property	Test Method	Performance Min.	Typical Performance – 60 mil
Overall Thickness	D412	0.0504 in (1.372 mm)	0.059 in (1.499 mm)
Tensile Strength	D 412 (Die C)	1305 psi (9.0 MPa)	1454 psi (10.0 MPa)
Elongation, Ultimate	D 412 (Die C)	300%	622%
Tensile Set	D412 Method A (Die C)	10%	2.18%
Tear Resistance	D 624 (Die C)	159 lbf/in (26.3 kN/m)	219 lbf/in (38.4 kN/m)
Brittleness Point	D2137	-49 °F (-45 °C)	-49 °F (-45 °C)
Ozone Resistance, no cracks	D1149	--	Pass
Heat Aging:	D 573	--	--
Tensile	D 412 (Die C)	1205 psi (8.3 MPa)	1490 psi (10.3 MPa)
Elongation, Ultimate	D 412	200%	322%
Tear Resistance	D 624	125 lbf/in (21.9 kN/m)	179 lbf/in (31.3 kN/m)
Linear Dimensional Change	D 1204	± 1.0%	-0.32%
Water Absorption	D471	+8%, -2 %	+1.515
Weight	---	---	.47 lb/ft ²
Factory Seam Strength	D 816 Method B (Modified)	50 lbf/in (8.8 kN/m) or Sheet Failure	Sheet Failure
Weather Resistance:	---	---	---
Visual Inspection	D 518	Pass	Pass
PRFSE	D 518	30%	53%
Elongation, Ultimate	D 412 (Die C)	200%	255%
Air Permeance (Material)	E 2178*	<0.004 ft ³ /ft ² (0.02 L/(s·m ²))	Pass

*The ASTM 2178 values listed are for the air permeance of the RubberGard EPDM SA membrane component only. For use of the product as a component in an air barrier assembly, please consult your Holcim Building Systems Advisor (BSA), Code Agency or Authority having Jurisdiction (AHJ) for the acceptable air barrier assembly details.

Substrates			
Acceptable Substrates	Primer Req'd	Acceptable Application Temperatures	Special Application Considerations / NOTE
ISO 95+™ GL / ISOGARD GL	No	20 - 120 °F (-7 - 49 °C)	---
ISOGARD HD	No	20 - 120 °F (-7 - 49 °C)	Do not roll in place with weighted roller
Resista / ISOGARD CG	No	20 - 120 °F (-7 - 49 °C)	Do not roll in place with weighted roller
Structural Concrete	No	20 - 120 °F (-7 - 49 °C)	Must be clean, dry, and properly cured prior to application
Lightweight Concrete	No	20 - 120 °F (-7 - 49 °C)	Use on clean, dry and properly cured cellular lightweight concrete only, not acceptable with lightweight aggregate concrete
DensDeck* Prime	No	20 - 120 °F (-7 - 49 °C)	---
Securock**	No	20 - 120 °F (-7 - 49 °C)	---
Plywood	No	20 - 120 °F (-7 - 49 °C)	Check local code for acceptance of direct application
OSB Board	No	20 - 120 °F (-7 - 49 °C)	Check local code for acceptance of direct application
CMU / Masonry and Vertical Substrates	Yes	20 - 120 °F (-7 - 49 °C)	Must be clean & dry prior to application. Apply Single-Ply QuickPrime or Single Ply LVOC Primer to all vertical substrates.
* DensDeck is a registered trademark of the G-P Gypsum Corporation ** Securock is a registered trademark of the USG Corporation			

Please contact Holcim Technical Services at 800-428-4511 for further information.

This sheet is meant to highlight Elevate products and specifications and is subject to change without notice. Holcim takes responsibility for furnishing quality materials that meet published Elevate product specifications or other technical documents, subject to normal manufacturing tolerances. Neither Holcim nor its representatives practice architecture. Holcim offers no opinion on and expressly refuses any responsibility for the soundness of any structure. Holcim accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No Holcim representative is authorized to vary this disclaimer.