



NOTES:

- A. VISIT GCPAT.COM FOR THE MOST CURRENT DETAILS, INSTALLATION VIDEO AND PRODUCT DATA SHEETS
- B. RIPCORD® CAN BE REMOVED FROM VYCOR® FLASHING FOR EASE OF INSTALLATION
- C. INSTALL VYCOR® FLASHING AND VYCOR® enV-S™ TO FORM WATER SHEDDING LAPS
- D. INSTALL VYCOR® enV-S™ VERTICALLY OR HORIZONTALLY TO FORM WATER SHEDDING LAPS
- E. FOR SILL PAN DEPTHS GREATER THAN 6 INCHES, A SLOPED SILL IS REQUIRED IN ACCORDANCE WITH ASTM E 2112
- F. A BACK DAM CAN BE ACCOMPLISHED USING A WOODED FURRING STRIP OR BY FOLDING THE VYCOR® FLASHING ADHESIVE LAYER ONTO ITSELF
- G. LEAVE RELEASE PAPER ON LOWER HALF OF VYCOR® FLASHING SILL FLASHING FOR FUTURE TIE-IN TO VINYL SIDING
- H. EXTEND VYCOR® FLASHING OVER NAILING FLANGE OF THE LAST COMPLETE COURSE OF SIDING PANAL AND TRIM VYCOR® FLASHING TO PROTECT FROM PERMANENT EXPOSURE TO UV
- I. LEAVE RELEASE PAPER ON OR OTHER BOND BREAKER BETWEEN VYCOR® FLASHING AND VINYL
- J. INSTALL VYCOR® FLASHING AROUND REMAINING WINDOW UNIT PER WINDOW DETAILS (VCRDET-100 TO 111)
- K. DETAIL ALSO RELEVANT FOR ALL VYCOR® FLASHINGS



gcpat.com

TIE-IN WITH VINYL SIDING AT WINDOW SILL

VYCOR® SELF-ADHERED FLASHING

Drawing: **VCRENVS-107**

Scale: **Not to scale**

Effective Date: **08/04/19**

Supersedes: **NEW**