

Product Certification

Henry® Blueskin SA and Blueskin SA LT Air and Vapor Barrier

Blueskin SA and Blueskin SA LT are self-adhered air and vapor barriers comprised of a rubberized asphalt adhesive factory-applied to a poly film intended for use in above grade wall assemblies. Henry products are tested to confirm compliance with the physical properties as stated on the product data sheet.

Blueskin SA and Blueskin SA LT have been evaluated in accordance with the following:

- ASTM E2357 – Assembly Air Leakage
- CAN/ULC-S742-2020 – Standard for Air Barrier Assemblies - Specification
- NFPA 285 – Complies in various wall assemblies
- Air Barrier Association of America: Evaluated air barrier material and air barrier assembly

Blueskin SA and Blueskin SA LT are chemically compatible with the following substrates:

- Precast and cast-in place concrete, masonry, steel, aluminum, galvanized metal, exterior grade gypsum board, foil or coated-glass faced polyisocyanurate foam sheathing, OSB and plywood

Blueskin SA and Blueskin SA LT are suitable for installation in conjunction with the following commonly used Henry products when installed per Henry published literature. Refer to product specific technical data sheet, guide specification, technical bulletins, and details for test data, installation guidelines, and sequencing requirements.

- Air-Bloc® 16MR
- Air-Bloc 17MR
- Air-Bloc LF® Liquid-Applied Flashing
- Aquatac™ Primer
- Barribond HP
- Barritech VP
- Barritech NP / Barritech NP LT
- BlueGRIP™
- Blueskin Adhesive
- Blueskin LVC Adhesive
- Blueskin LVC Spray Primer
- Blueskin PE200HT
- Blueskin Spray Prep
- Blueskin TWF Thru-Wall Flashing
- Blueskin VP160
- Blueskin WP200
- Blueskin ZeroFlash™
- CAV-GRIP™
- CCW-702
- CCW-702 LV
- CCW-702 WB
- CCW-705 / CCW-705 XLT / CCW-705 HT
- CCW-705-TWF
- Henry 925 BES Sealant
- Hi-Tac™ Primer
- MiraDRI 860 / 861
- Metal Clad 705FR / Metal Clad 705FR LT
- Travel Tack

Blueskin SA and Blueskin SA LT are suitable for installation in conjunction Air-Bloc All Weather STPE when installed prior to Air-Bloc All Weather STPE per Henry published literature. Install Blueskin ZeroFlash with Aquatac Primer as a transition flashing where asphaltic membranes are installed onto cured Air-Bloc All Weather STPE.

Blueskin SA and Blueskin SA LT have a VOC content of 0 g/L, max.

*Information is based on Henry test data, experience, and knowledge and is considered to be true and accurate. Refer to Henry Technical Data sheets and Safety Data Sheets prior to use. No warranty or guarantee, expressed or implied, is given other than those required by law.