




KWIK HUS-EZ	$h_1^*$	$t_{\text{fix}}$
$3/4 \times 4\frac{1}{2}$	$4\frac{7}{8} - t_{\text{fix}}$	0... $1\frac{1}{2}$
$3/4 \times 5\frac{1}{2}$	$5\frac{7}{8} - t_{\text{fix}}$	0... $1\frac{1}{2}$
$3/4 \times 7$	$7\frac{3}{8} - t_{\text{fix}}$	0... $3/4$
$3/4 \times 8$	$8\frac{3}{8} - t_{\text{fix}}$	0... $1\frac{3}{4}$
$3/4 \times 9$	$9\frac{3}{8} - t_{\text{fix}}$	0... $2\frac{3}{4}$



<b>2.1</b>		
SIW 22T/18T-A	✓	✓
	115 ft-lb	70 ft-lb



\*For non-hole cleaning installation (steps 1a or 1b), make sure to drill deep enough to achieve  $h_1$ , taking into account the depth of debris remaining in the hole.