


NOTES:

1. DETAILS TO BE USED IN CONJUNCTION WITH GUIDE SPECIFICATIONS CONTAINING REQUIREMENT FOR NAILERS, INSULATION, ETC.
2. JM TPO EDGE SEALANT IS USED TO SEAL THE MEMBRANE EDGES WHERE REINFORCING FABRIC IS CUT AND EXPOSED. EDGE SEALANT IS REQUIRED ON ALL END LAPS, T-JOINTS AND CUT EDGES.
3. IN NEW CONSTRUCTION, ACCEPTABLE SUBSTRATES INCLUDE EXTERIOR GRADE PLYWOOD, POURED OR PRECAST CONCRETE, CEMENT BLOCK OR MASONRY WALLS. CONTACT JM TECHNICAL SERVICES FOR OTHER SUBSTRATES.
4. ON REROOFING PROJECTS, AN ACCEPTABLE ASPHALT BARRIER SHOULD BE INSTALLED OVER THE EXISTING FLASHING TO FULLY DIVORCE THE JM TPO REINFORCED FLASHING MEMBRANE FROM ANY INCOMPATIBLE MATERIALS.
5. APPROVED FASTENER MUST BE WITHIN 3" (80 mm) OF VERTICAL SUBSTRATE. MEMBRANE AREAS BETWEEN AND BEHIND THE PLATE MUST BE WELDED SOLID ALL THE WAY TO THE VERTICAL SUBSTRATE.
6. IF THE BACK EDGE OF THE INSEAM PLATE IS GREATER THAN 2" (50 mm) FROM THE VERTICAL SUBSTRATE, THE WALL FLASHING MUST BE ADHERED UTILIZING JM TPO BONDING ADHESIVE.
7. REFER TO DETAIL TB-26 WHERE FASTENER CAN NOT BE INSTALLED WITHIN 3" (80 mm) OF VERTICAL SUBSTRATE.
8. INSULATION MUST BE COMPATIBLE WITH JM TPO BONDING ADHESIVE.

DRAWING NO. TB-25	BASE TIE-IN (FASTENER AND PLATE)			 Johns Manville
	SCALE N.T.S.	ISSUE DATE 3-06	CAD TPO-3.10	