

🐼 MAPEI°

# DESCRIPTION

*MapeWrap G Uni-Ax* is a high-strength, uni-directional E-glass fiber fabric that, when used with the *MapeWrap* family of two-component epoxy adhesives, forms an externally bonded fiber-reinforced polymer (FRP) reinforcement system engineered to increase the strength of structural elements. When applied to the surface of structural members in buildings, parking garages, bridges, marine piles and other structures, *MapeWrap G Uni-Ax* improves the seismic performance of concrete columns, masonry and concrete walls, and concrete beam-column connections.

## FEATURES AND BENEFITS

- High strength-to-weight ratio
- Use for confinement, shear or flexural strengthening.
- Non-corrosive
- Low aesthetic impact (easy to conceal)

- Installs quickly, with no special machinery or equipment
- Flexible; will conform to shape of complex surfaces that need repair
- Economical
- Can be used on concrete, masonry, wood and steel substrates

#### WHERE TO USE

- Restores structural integrity to damaged or deteriorated concrete surfaces caused by fire, impact or aging
- Improves seismic strength of masonry and concrete shear walls, columnbeam connections and concrete columns

- Increases ductility and load-bearing capacity of concrete beams, slabs, columns and walls due to design defects, change of use, and increased service loads in buildings, parking garages and bridges
- Seismic strengthening and restoration of vaulted elements and arches found in historical buildings, tunnels and highway structures
- Use for vertical and horizontal installations, and for interior and exterior applications.

### LIMITATIONS

- Application temperature of the epoxy adhesive being used should be between 41°F and 86°F (5°C and 30°C). Contact MAPEI's Technical Services Department for installation recommendations when ambient temperatures fall above or below this temperature range.
- Design calculations and project review should be carried out by an independent licensed engineer with carbon-fiber-reinforced polymer (CFRP) and/or glass-fiber-reinforced polymer (GFRP) design experience, and in accordance with all state, provincial and federal building codes. Additional design examples/guidelines are available upon request from MAPEI's Technical Services Department.

### SUITABLE SUBSTRATES

• Use for interior/exterior applications on 28-day-old cured concrete, masonry, wood and steel.

Consult MAPEI's Technical Services Department for installation recommendations regarding substrates and conditions not listed.



# SURFACE PREPARATION

- Concrete surfaces must be fully cured, clean, sound, and dry and free of cavities or protrusions.
- Remove all fins and sharp protrusions, and detail element as illustrated on the engineering documents.
- Remove all bond-inhibiting materials including dust, laitance, oils, impregnations, coatings, form release agents or any surface contaminants – before installation.
- Defects in the concrete substrate must be repaired and any surface cracks greater than 10 mils (0,3 mm) must be sealed with MAPEI's epoxy injection products, such as *Planibond*<sup>®</sup> AE and/or *Planibond CR 50*.
- Clean all exposed reinforcement in accordance with the Steel Structures Painting Council (SSPC) and coat with *Planibond 3C* or *Mapefer*<sup>™</sup> 1K.
- Mechanically prepare the substrate to provide a proper surface profile, as determined by the engineer. The surface profile typically should be a minimum International Concrete Repair Institute (ICRI) concrete surface profile (CSP) of #3 to #5. In all cases, it is the responsibility of the engineer to assess and specify the appropriate anchor profile required to ensure system performance.
- Test the prepared surface, as directed by the engineer. Adhesive strength to concrete should meet a minimum tensile strength of 200 psi (1,38 MPa) and exhibit failure within concrete substrate. Random pull-off testing (per ACI 503R) should be completed after the appropriate surface preparation has been achieved.

## MIXING

Note: Choose all appropriate safety equipment before use. Refer to (Material) Safety Data Sheet for more information.

- 1. Refer to individual MAPEI Technical Data Sheets (TDSs) for the appropriate epoxies to be used with *MapeWrap G Uni-Ax*.
- 2. Do not dilute or modify epoxies.

# **PRODUCT APPLICATION**

*MapeWrap G Uni-Ax* can be installed using the "dry" or "wet" layup method.

Common to both dry and wet layups

- 1. The installer and owner should read and follow all recommended personal protection equipment (PPE) procedures while preparing and installing *MapeWrap G Uni-Ax* and its adhesives.
- 2. When the product is applied in a closed environment, provide good ventilation. For further information, carefully read the (M)SDS of each of the products used.
- 3. Cut MapeWrap G Uni-Ax to the desired length.
- 4. Prime the surface that needs to be reinforced with a brush or roller and an even coat of *MapeWrap Primer 1* at a rate of 150 to 190 sq. ft. per U.S. gal. (3,67 to 4,65

m<sup>2</sup> per L). Very porous substrates may require a second coat after the first coat has been completely absorbed.

- 5. On concrete surfaces sealed with MapeWrap Primer 1 but requiring smoothing/leveling, apply a layer (average thickness of 1/32" [1 mm] and maximum thickness of 1/6" [4 mm]) of MapeWrap 11 or MapeWrap 12 using a notched trowel, while the primer is still wet or tacky. Use a flat trowel to smooth the surface and remove any imperfections. For higher thickness, use Planitop<sup>®</sup> X or Planitop XS.
- 6. When wrapping columns, *MapeWrap G Uni-Ax* must be overlapped by 8" (20 cm) with the same fabric.

### <u>Dry layup</u>

- Spread an even first coat of *MapeWrap 31* with a brush or short-nap roller at a thickness of 20 mils (0,5 mm) and rate of 40 to 45 sq. ft. per U.S. gal. (0,98 to 1,10 m<sup>2</sup> per L), while *MapeWrap 11* or *MapeWrap 12* is still wet or tacky.
- Immediately place MapeWrap G Uni-Ax over the stilltacky or -wet MapeWrap 31, using a gloved hand (refer to the (M)SDS for proper personal protection equipment [PPE]) to thoroughly flatten out the fabric, and then use a hard plastic roller to smooth out any wrinkles or air pockets. The roller should be run only in the direction of the primary fibers in the fabric.
- 3. Use a rubber roller to push the epoxy through the fibers on both sides of the fabric, and then apply a second coat of *MapeWrap 31* over the exposed surface to completely encapsulate the fabric. Use an aluminum worm screw roller to completely eliminate any remaining air bubbles formed during the application.
- 4. Broadcast sand to rejection onto the wet surface of MapeWrap 31 and cover with a protective coating, such as Mapelastic<sup>™</sup> flexible, cementitious waterproofing mortar, or Mapecoat<sup>™</sup> AP flexible acrylic paint, to provide an effective barrier against ultraviolet (UV) rays, particularly in direct sunlight.

## <u>Wet layup</u>

- MapeWrap G Uni-Ax should be impregnated with MapeWrap 21 using an automated, mechanically driven saturation device. This is a simple machine fitted with a bucket and a series of rollers that automatically saturates the fabric and allows any excess saturant to drip from the fabric easily and safely.
- As an alternative, MapeWrap G Uni-Ax can be plunged into a plastic trough filled with 1/3 of the total volume with MapeWrap 21. Remove the fabric from the trough, let it drip and press it between gloved hands until the excess resin is completely removed. Take precaution not to wring the fabric and damage the E-glass fibers.
- 3. Once *MapeWrap G Uni-Ax* is saturated, apply it over the still-wet *MapeWrap 11* or *MapeWrap 12* that covers *MapeWrap Primer 1*, or over *MapeWrap Primer 1* alone if a fast-setting mortar was used. Use a gloved hand (refer



## **Product Performance Properties**

Laboratory Tests	Results
Fiber material	High-strength E-glass
Color	White
Primary fiber direction	0° (uni-directional)
Shelf life	Unlimited in proper storage conditions; store in a dry place with no exposure to direct sunlight
Weight	26.5 U.S. oz. per sq. yd. (900 g per m <sup>2</sup> )

## **Dry Fiber Properties**

Property	Typical Test Value
Base	High-strength, uni-directional E-glass fiber fabric
Ultimate tensile strength	371,297 psi (2,56 GPa)
Tensile modulus	11,704 psi (80,7 MPa)
Elongation at break	3%
Nominal thickness (t <sub>f</sub> ):	0.0139" per ply (0,353 mm per ply)

## Cured Laminate Properties with MapeWrap 21

Properties	Average Value	Design Value <sup>1</sup>	ASTM Test Method
Tensile strength*	69,000 psi (476 MPa)	43,000 psi (297 MPa)	D3039
Tensile modulus*	3,292,000 psi (22 703 MPa)	3,292,000 psi (22 703 MPa)	D3039
Elongation at break*	2.1%	1.4%	D3039
Ply thickness (inch/mm)*	0.0517 (1,313)	0.0517 (1,313)	-

## Cured Laminate Properties with MapeWrap 31

Properties	Average Value	Design Value <sup>1</sup>	ASTM Test Method
Tensile strength*	54,000 psi (372 MPa)	42,000 psi (290 MPa)	D3039
Tensile modulus*	2,586,000 psi (17 834 MPa)	2,586,000 psi (17 834 MPa)	D3039
Elongation at break*	2.1%	1.8%	D3039
Ply thickness (inch/mm)*	0.0701 (1,780)	0.0701 (1,780)	-

\* 24 sample coupons per test series according to ACI 440. Testing is in accordance with ASTM D3039.

<sup>1</sup> Average value minus 3 standard deviations

Packaging		
Product Code	Size	
7303450	164-ft. (50,0-m) roll at 23.6" (60 cm) wide	
Made to order	164-ft. (50,0-m) roll at 11.8" (30 cm) wide	







to the [MJSDS for proper PPE) to thoroughly flatten out the fabric, and then use a hard plastic roller to smooth out any wrinkles or air pockets. The roller should be run only in the direction of the primary fibers in the fabric.

- 4. Pass over the impregnated fabric with a worm screw roller in order to completely eliminate any air bubbles formed during application of the fabric.
- 5. Broadcast sand to rejection onto the wet surface of MapeWrap 21 covering MapeWrap G Uni-Ax and cover with a protective coating, such as Mapelastic flexible, cementitious waterproofing mortar, or Mapecoat AP flexible acrylic paint, to provide an effective barrier against UV rays, particularly in direct sunlight.

## CLEANUP

Due to the high bond strength of *MapeWrap 11*, *MapeWrap 12*, *MapeWrap 21* and *MapeWrap 31* on metal, tools should be cleaned with approved solvents (ethyl alcohol, toluene, etc.) before the product dries. Cured materials can only be removed mechanically. Dispose of in accordance with local disposal regulations.

Refer to the (M)SDS for specific data related to VOCs, health and safety, and handling of product.

## STATEMENT OF RESPONSIBILITY

Before using, user shall determine the suitability of the product for its intended use and user alone assumes all risks and liability whatsoever in connection therewith. <u>ANY CLAIM SHALL BE DEEMED WAIVED UNLESS</u> <u>MADE IN WRITING TO US WITHIN FIFTEEN (15) DAYS</u> FROM DATE IT WAS, OR REASONABLY SHOULD HAVE BEEN, DISCOVERED.



For the most current BEST-BACKED<sup>™</sup> product data and warranty information, visit www.mapei.com. All Rights Reserved. Printed in the USA. © 2013 MAPEI Corporation.