

 **METZGER/McGUIRE**

SPF

**Stain Preventing Film for
Epoxy & Polyurea Joint Fillers**

The proper installation of semi-rigid fillers for filling joints in industrial concrete floors calls for the joints to be overfilled. The overfill is later razored off flush, but can leave staining on the floor surface. This staining can be eliminated or greatly reduced by treating the floor with SPF before filling.

**Ideal for most epoxy
and polyurea joint fillers**

**Drys fast (15-30 mins.)
and is non-slippery once
dried**

**Protects conventional,
colored, stained and
sealed surfaces**

**Drys clear, but exhibits
shadow to verify proper
application**



**Less expensive than
other stain-preventing
methods (taping, etc.)**

**Water soluble for safety
and ease of removal**

**Won't harm scrubbing
equipment, flush down
drain with rinse water**

**No VOC's, negligible
odor, easy to apply.**

SPF works by creating a film on the concrete adjacent to the joint being filled. This film barrier prevents the filler from staining the concrete. After the overfill has been razored off, the SPF can be allowed to self-disintegrate or can easily be removed with normal scrubbing operations.

**When the aesthetics of your joint filler installation are important,
Metzger/McGuire's SPF is your best method of stain prevention.**

 **METZGER/McGUIRE**

*Industry Standard Epoxy and Polyurea
Floor Joint Fillers and Repair Products*

800-223-MM80

www.metzgermcguire.com

P.O. Box 2217 Concord, NH 03302

E-Mail: specmm80@aol.com Fax: 603-224-6020