

Pre-Form 100 seals and protects plywood form surfaces, creating an impact-resistant, glossy, seamless, smooth and long-lasting casting surface by eliminating concrete surface voids and other surface irregularities. Sealing plywood forms prevents wood grain transfer and protects concrete surfaces from sugar-related discoloration and staining.

### EQUIPMENT REQUIRED

- Heavy-duty drill fitted with a flat-blade mixing paddle
- · 3 buckets or suitable measuring and mixing vessels
- · Notched squeegee or roller applicator
- 3/8 (1.0 cm) nap cover
- Spiked roller
- Wet Film Thickness Gauge
- · Spiked Shoes for working on wet surface

## FORM PREPARATION

**New Plywood Forms:** Clean and dry forms until they are free from dust, dirt and all foreign matter. Fasten down the wood substrate and fill any large imperfections, holes and joints.

**Previously Sealed Plywood Forms:** Sand with an orbital floor sanding machine using 100-grit sandpaper. Fill any large imperfections, holes and joints Then scrub forms with Nox-Crete's Bio-Clean citrus based degreaser and rinse with water. Allow forms to dry prior to Pre-Form 100 application.

# All Plywood Forms:

- Dam form edges to prevent Pre-Form 100 from dripping off the sides.
- Calculate the surface area to be coated with Pre-Form 100 and divide the total area into small batch quantities. Mark the form surface to indicate the areas that will be covered by each batch. SEE COVERAGE RATE TABLE 3 ON PAGE 2
  - » For example, if the area to be coated is 450 ft² with a heavy film thickness (32 mil) desired, mark off three 150 ft² sections, then mix and apply one 3 gallon batch at a time to allow for ample work time before product starts to cure and a consistent surface finish.

# PRODUCT PREPARATION

The correct mixing ratio is 2 parts Component A (epoxy resin) to 1 part Component B (hardener). Failure to properly mix components will negatively affect product performance.

### **MEASURING**

- To mix a pre-measured 4 gallon (15.1 L) kit, simply pour Component B into the Component A bucket and mix for 3-4 minutes.
- To mix bulk product, use exact measurements to measure two (2) parts Component A and one (1) part Component B by volume in separate containers. SEE MIX RATIO TABLE 1 AND TABLE 2 ON PAGE 2
- Pour the pre-measured components A and B into a third container, suitable for mixing.
- If applicable, measure and add .9 lb of red pigment OR 1.72 lb of white pigment per gallon to the mixture. SEE OPTIONAL MIX RATIO TABLE 4 ON PAGE 2

# **MIXING**

- Mix properly measured Components A & B thoroughly for 3-4 minutes.
- Use a heavy-duty drill fitted with a flat-blade mixing paddle and mix at 400 rpm.
- Keep the paddle submerged in product at all times to minimize air incorporation.
- Move the mixer up and down throughout the liquid to ensure proper mixture.
- Immediately (within 5 minutes) apply Pre-Form 100 after mixing, following Application Instructions on Page 2.



# **APPLICATION GUIDE**

# PRE-FORM 100

# **APPLICATION**

- Do not apply in direct sunlight. Apply in shade or when sun is at low angle.
- Do not leave mixed product in bucket. This generates heat, causing product to quickly thicken and cure.
- Do not scrape sides of mixing bucket when pouring as this may lead to uncured product on the form surface.
- · Do not overwork applied product.
- The typical application rate on standard horizontal plywood forms is 50-100 sf/gal (1.25 -2.5 sm/L) or 16-32 mil (400-800 u).

**Previously Sealed Plywood Forms:** Generally, only one application of Pre-Form 100 is required for plywood forms that have been previously sealed and prepped according to Form Preparation instructions.

- Pour Pre-Form 100 out in ribbons on the form within 5 minutes after mixing. Once poured, there is a 40-minute working time for maximum performance.
- Using a notched squeegee or roller applicator equipped with a 3/8 inch (1.0 cm) nap cover, spread the product evenly to desired film thickness.
- 3. For larger areas, use Nox-Crete's 18-inch (45 cm) wide roller applicator with a 12-foot (3.6 m) extension pole handle.
- Quickly back roll applied product to achieve a uniform film thickness.
- 5. Check thickness with a wet film thickness gauge.
- Use a spiked roller to eliminate air bubbles and spread the product, if necessary.

**New Plywood Forms:** If this is the first application on a new plywood form, two coats of Pre-Form 100 are required to mask raised wood fibers.

- Using the tools and methods described previously, apply a light, seal coat.
- 2. Allow product to cure undisturbed and protected for 6-24 hours, depending on curing temperatures.
- Once fully cured, power sand surface with an orbital floor sanding machine to smooth any imperfections or bubbles.
- 4. Remove dust or debris caused by sanding.
- 5. Apply a second, light coat.

# AFTER APPLICATION

- Always allow product to cure undisturbed and protected for 6-24 hours, depending on curing temperatures.
- Sand surface with an orbital floor sanding machine and remove dust and debris before concrete application.
- Do not return unused material to original container.
- Clean application equipment immediately with Nox-Crete Solvent B.

### **TABLE 1. MIX RATIO BY VOLUME**

Mixing	Mixed Volume Created			
Mixing Component	<b>1 Gallon</b> (3.8 <i>L</i> )	<b>3 Gallons</b> (11.4 L)	<b>5 Gallons</b> (19 L)	
Component A 2 Parts	85.33 oz	256 oz	426.67 oz	
	(2.53 L)	(7.6 L)	(12.65 L)	
Component B	42.67 oz	128 oz	213.33 oz	
1 Part	(1.27 L)	(3.8 <i>L</i> )	(6.35 L)	

#### **TABLE 2. MIX RATIO BY WEIGHT**

Mixing Component	Mixed Volume Created		
	<b>1 Gallon</b> (3.8 <i>L</i> )	<b>3 Gallons</b> (11.4 L)	<b>5 Gallons</b> (19 L)
Component A	6.250 lb	18.750 lb	31.250 lb
67.6%	(2.835 kg)	(8.505 kg)	(14.175 kg)
Component B	2.905 lb	8.715 lb	14.525 lb
31.4%	(1.318 kg)	(3.953 kg)	(6.588 kg)
Total Combined	9.115 lb	27.465 lb	45.775 lb
Weight	(4.153 kg)	(12.458 kg)	(20.763 kg)

## **TABLE 3. COVERAGE RATE (AFTER MIXED)**

		Area Covered			
Wet Film Thickness		<b>1 Gallon</b> (3.8 L)	3 Gallons (11.4 L)	<b>5 Gallons</b> (19 L)	<b>10 Gallons</b> (38 L)
Maximum	125 mil (3.3 mm)	13 ft² (0.32 m²)	39 ft² (0.96 m²)	65 ft² (1.6 m²)	130 ft² (3.19 m²)
Heavy	32 mil (800 μ)	50 ft² (1.23 m²)	150 ft² (3.68 m²)	250 ft <sup>2</sup> (6.14 m <sup>2</sup> )	500 ft <sup>2</sup> (12.27 m <sup>2</sup> )
Light	16 mil (400 μ)	100 ft² (2.45 m²)	300 ft <sup>2</sup> (7.36 m <sup>2</sup> )	500 ft <sup>2</sup> (12.27 m <sup>2</sup> )	1000 ft <sup>2</sup> (24.54 m <sup>2</sup> )

### **TABLE 4. OPTIONAL MIXING RATIO FOR PIGMENT**

	Mixed Volume Created		
Pigment Color	1 Gallon (3.8 L)	3 Gallons (11.4 L)	<b>5 Gallons</b> (19 L)
Red Pigment	0.9 lb	2.7 lb	4.5 lb
	(0.408 kg)	(1.225 kg)	(2.041 kg)
White Pigment	1.72 lb	5.16 lb	8.6 lb
	(.780 kg)	(2.340 kg)	(3.900 kg)

Note: Proper mixing of Pre-Form 100 White will result in additional volume per mixed gallon.

See **Product Data Sheet** & **Troubleshooting Guide** for more information.

