



## INSTALLATION DESIGN CONSIDERATIONS

- Establish thermal breaks to reduce condensation on cold surfaces.
- The need for and placement of vapor retarders should be determined by the building designer.
- Minimize penetrations of insulation by structural elements, wall attachment devices, etc. In constructions using a vapor retarder, careful consideration should be given to maintaining vapor retarder integrity.
- Buildings using curtainwall construction should be equipped with a sprinkler system to provide adequate fire protection.
- When specifying kraft-faced or standard foil-faced insulation check local code requirements for limitations and install facing in substantial contact with finish surface.
- Provide code required fire separation between floors.
- Architect must supply detailed drawings to meet project and building code requirements.



## PRODUCT OPTIONS

- ▶ 700 Series Insulation
- ▶ Flame Spread 25 Insulation
- ▶ Thermal Batt Insulation

© 1996 – 2002 by  
Owens Corning