


Tapered Ultra-Max® : Insulation for Above the Deck Built-Up Roof (BUR) Application

Specify and install Tapered Ultra-Max® for use with BUR membrane systems. Secure the Tapered Ultra-Max® to flat, smooth, dry roof decks with FM approved mechanical fasteners using one (1) fastener every four (4) square feet of insulation surface. Tapered Ultra-Max® may be adhered to properly prepared concrete deck surfaces in solid flood coats of hot bitumens. Rmax recommends that when Tapered Ultra-Max® is used under a BUR membrane system, it be properly protected by an overlay of mineral fiberboard, wood fiberboard, gypsum board, perlite or a venting base sheet as specified in the NRCA "Technical Bulletin #9".

Refer to Tapered Ultra-Max® data sheet for additional application/installation, compliances, thermal and physical properties, limitations and warnings.



Notes:

1. Vapor retarders should be applied as required and recommended by the NRCA.
2. Insulation and cover board may be applied using air-cured polyurethane foam as applicable.

*Warranty: See Rmax "Sales Policy" and applicable warranties for terms and conditions. Rmax does not assume any responsibility or liability for the performance of any products other than those manufactured by Rmax. **NOTE: All Rmax products must be tarped, placed on skids and kept dry before and throughout construction. Requests for Certification Letters and/or special warranty considerations must be submitted to Rmax Sales prior to delivery of the products.***

2017-11