

# Waterproofing and Drainage Selection Guide\*

TREMproof®, Paraseal® and TREMDrain®

	FLUID	TP250 GC	TP201/60	TP260	TP6100	SHEET	Paraseal	Paraseal LG	Paraseal GM	Paraseal GM/LG 20mil	Paraseal GM/LG 60mil	DRAINAGE	TREMDrain	TREMDrain S	TREMDrain 1000	TREMDrain 1000 PF	TREMDrain 2000	TREMDrain Total Drain	TREMDrain QSP
<b>Vertical</b>																			
Backfilled Wall (<20')	•	•	•				•	•					•					•	•
Backfilled Wall (>20')	•	•					•	•						•	•			•	•
Blindside/Lagging Wall (<20')								•	•	•			•					•	•
Blindside/Lagging Wall (>20')								•	•	•				•	•			•	•
<b>Horizontal</b>																			
Split Slab or Paver	•				•									•		•	•		
Below Slab on Grade							•		•	•				•					
Planters	•				•												•		
<b>Other</b>																			
Methane Barrier**			•					•		•									
Submerged Conditions**	•			•					•	•									
Green/Damp Concrete	•		•			•	•	•	•	•		•	•	•	•	•	•	•	•
<p>* The Waterproofing &amp; Drainage Selection Guide is to be used as general reference and reflects two of the components that become integrated into a water proofing system. Please consult your local Tremco Manufacturer's Representative for regional recommendations based on your local building practices and warranty requirements.</p> <p>** Please consult your local Tremco Manufacturer's Representative for recommendations and approval of your specific application. Reference the current product data sheet on our website at <a href="http://www.tremcosealants.com">www.tremcosealants.com</a> for more specific product information. For priming recommendations, please contact Tremco Technical Services or reference the Primer Guide on our web site.</p>																			