



Aquaflash 500 Installation Instruction

*** Note: A Termination Bar is required for surface-mounted applications.**

1. Aquaflash 500 should be cut into manageable lengths of approximately 8 to 10 feet.
2. Remove the release liner.
3. Apply Aquaflash 500 membrane starting from the lowest point and work upwards.
4. Once the membrane is in place, use a steel hand roller to secure the flashing firmly in place.
5. All side laps should be a minimum of 4". Either trim edges or lay the membrane 1/2" back from face of masonry.
6. After installing the overlapping section of flashing, apply a 1/2" thick bead of Aquaflash 500 Mastic along the joint and tool it down to 1/4" with an 1-1/2" wide putty knife.
7. * Install Termination Bar at the top of the flashing to secure it to the backup.
8. Inside and outside corners must be covered with two layers of membrane and sealed with mastic.

Once installed, no maintenance is required.

Note: Not to be used for exposed flashing.

Not to be applied below 25°F Not to be applied below 40°F without a primer Not to be used with oil based, wax based or polysulfide sealants or creosote.
Rubberized asphalt flashings not to be exposed for more than 3-4 weeks.

Repairs:

Aquaflash repairs are made by using a piece of Aquaflash cut to extend 6" in all directions from the edge of the affected area. The piece used should be put in place by using a hand roller.

Storage:

Temperature not to exceed 120° Fahrenheit or go below 25° Fahrenheit.

Protect products from inclement weather or excessive heat.

Sizes: Standard Widths: 12", 16", 18" 24",36" Standard Length: 50 lineal feet.

Corporate Office: 400 Rountree Rd Charlotte, NC 28217
TEL: (800) 849-6722 FAX: (704) 525-3761

Mailing Address: P.O. Box 240988 Charlotte, NC 28224



www.wirebond.com

Memphis Plant: 2365 Harbor Ave. Memphis, TN 38113
TEL: (800) 441-8359 FAX: (901) 775-9449

Mailing Address: P.O. Box 13124 Memphis, TN 38113